

The "EZ" Electronic Scale Indicators



EZ VIEW 150



EZ 210



Operation, Installation, and Technical Manual

DIGI-STAR 790 WEST ROCKWELL AVENUE FORT ATKINSON, WISCONSIN 53538 PHONE (920) 563-1400 (C) 1992-97 DIGI-STAR

3251 Rev B-1 9/97

Printed in U.S.A.



Θ

()





FEATURES 5 OPERATING SPECIFICATIONS 5 MODEL 150 - System Operation: 6 Turning ON the Scale: 6 Turning OFF the Scale: 6
OPERATING SPECIFICATIONS 5 MODEL 150 - System Operation: 6 Turning ON the Scale: 6 Turning OFF the Scale: 6
MODEL 150 - System Operation: 6 Turning ON the Scale: 6 Turning OFF the Scale: 6
Turning ON the Scale: 6 Turning OFF the Scale: 6
Turning OFF the Scale: 6
To Zero-Balance the Scale:
To Select Gross Mode:
To Select Net Mode:
MODEL 150 - Ontional Features:
Remote Display Ontion:
TR Option: Radio Control
Installation Requirements. 8
Indicator Mounting:
Dower Connection:
Load Call Connection
Lightning Protection:
MODEL 210 - System Operation:
Turning ON the Scale:
Turning OFF the Scale:
To Zero-Balance the Scale:
Using the Heln Key
To Select Gross Mode:
To Select Not Mode: 10
To Enter a Preset:
To Clear the Preset & Alarm:
To Preload a Tare Value: 12
Using the Pre-Alarm:
Change the Pre-Alarm Weight:
Installation Requirements:
Indicator Mounting:
Power Connection:
Remote Alarm Connection:
Remote Input Connection:
Load Cell Connection:
Lightning Protection:

MODE	L 210 - Optional Features:	15
	Remote Display:	15
	TR-TR4: Radio Control	15
	To Print:	15
	Enter Identification Number: ID#	15
	Display Identification Number:	15
	Add Weight To Weigh Memory:	16
	Recall Weigh Memory:	16
	Print Weigh Memory:	16
	Clear Weigh Memory:	16
	Black Out:	17
	Pulsed Output:	17
MODE	EL 320 - System Operation:	18
	Turning ON the Scale:	18
	Turning OFF the Scale:	18
	To Zero-Balance the Scale:	18
	Using the Help Key:	19
	To Select Gross Mode	19
	To Select Net Mode	19
	To Enter a Preset	$\frac{1}{20}$
	"GROSS MODF"	$\frac{20}{20}$
	"I OAD/INI OAD MODE"	$\frac{20}{20}$
	"NFT MODE"	$\frac{20}{20}$
	To Clear the Preset Alarm:	$\frac{20}{21}$
	To Preload a Tare Value	$\frac{21}{21}$
	Using the Pre_{Δ} larm:	$\frac{21}{22}$
	Changing Pre-Alarm Weight	$\frac{22}{22}$
	To Start the Mix Timer	$\frac{22}{23}$
	To Clear the Mix Timer	$\frac{23}{23}$
	To De Start the Mix Timer.	$\frac{23}{23}$
	For the Mathedes	$\frac{23}{24}$
	To Change the Entry Method:	24
	To Change the Entry Method:	24
	To Edit a Desingu	20
	To East a Recipe.	29
	Io Erase a Recipe:	3U 21
		31 21
	Using Tolerance:	31 21
	Io Change the Tolerance:	21
	Using Delay Time:	32
	To Change the Delay Time:	32
		33
		33
Install	ation Doquiromants.	21
mstall	auon Acquirements	54 34
	Dowar Connection:	34 24
	Pomote Alarm Connection:	24 24
	Remote Input Connection:	54 24
	Load Call Connection:	54 24
		34 24
		54

MODEL 320 - Optional Features:	35
Remote Display:	35
TR: Radio Control Operation	35
To Print Weight Data:	35
To Print the Recipe Memory:	35
To Print a Single Recipe:	35
To Enter ID Numbers-I.D.#:	36
To Display ID Numbers-I.D.#:	36
Black Out:	37
Pulsed Output:	37
	•
REMOTE EZ R & EZ VIEW DISPLAYS - System Operation:	38
	38
Turning OFF:	38
Setup:	38
Installation Requirements:	38
Remote Display Mounting.	38
Power Connection	38
	50
Set Up / Calibration:	39
Entering & Exiting Setup Modes:	39
To Enter "Long Form" Setup/Calibration:	39
To Enter "Short Form" Setup:	39
To Exit either Setup:	39
Entering Setup/Calibration Values:	39
Short Form Set Up Values:	40
To enter the "Short Form":	40
Setup Number { SETUP }:	40
Calibration Number { CAL }:	40
Long Form Set Up Values - Section 1:	41
To enter the "Long Form":	41
Pre-Alarm Weight { P-ALM }:	41
Clock Time { TIME }:	41
Clock AM/PM { AM/PM }:	41
Clock Calendar { DATE }:	41
Clock Marque { MARQUE }:	41
Entry Method - Batcher { E MTHD }:	41
Tolerance - Batcher { TOLER }:	41
Delay - Batcher { DELAY }:	42
Motion { MOTION }:	42
Display Update Rate { D RATE }:	42
Weigh Method { W MTHD }:	42
Zero Tracking { ZTRACK }:	42
Long Form Calibration Values -Section 2:	42
Display Units { LB-KG }:	42
Capacity Limit { CAP }:	42
Display Count Increment { COUNT }:	42
Zero { ZERO }:	42
Full Scale Calibration { ADD WT }:	43

Long Form Setup Values - Section 3:	43
Remote Input { RM INP }:	43
Alarm Output { AL OUT }:	43
Remote Style { REMOTE }:	43
Alarm Buzzer { BUZZER }:	43
TR Inventory Hold { TR HLD }:	44
Raw A/D Display Counts { DSP AD }:	44
Clear Memory { CLR M }:	44
Tare Auto-Print { TAREAP }:	44
One Line Print { 1L PRT }:	44
Print Delay { PRTDLY }:	44
Estimated Weight { EST WT }:	44
Exiting Setup/Calibration Mode:	44
8 ~ F	
Test Mode:	45
Initiating Self Test:	45
Test Sequence	45
Start of Test Sequence:	45
Display Set Un Values.	
Display Set Op Values.	45
Display Test	45
Display Plogram ID.	43
	43
Self Test System Errors:	45
	45
Terminating the Test:	45
	1.0
Weighing Errors:	46
	46
Over Range:	46
Under Range:	46
Annunciators:	47
Appendix A: Short Form Calibration:	48
Appendix B: Long Form Setup and Calibration:	49
Appendix C: RS-232 Specifications:	50
Appendix D: Serial Cable Drawings:	57
Appendix E: Weigh Method Descriptions:	64
Index	65





Model EZ 150.

Model EZ 210.

TUTORIAL - Getting Started:

To operate the scale, first attach the scale's power cord to connector J901 and the loadcell cable to connector J902 on the bottom panel of the scale.



Press the [ON] key. A brief message is displayed (such as "HELLO").

The scale now enters the **GROSS** mode.



Press and release the [NET/GROSS] key, then within three seconds, press the [ZERO] key.

"ZERO" is displayed to show completion of the "ZERO/BALANCE" step.

Now the scale is ready to weigh!

FEATURES: The "EZ" Model Series has enhanced features such as:

- User friendly Help Messages for EZ operation.
- Front Panel Calibration without simulator or weights.
- Large 1 inch alpha-numeric display for greater readability.
- Fiber-optic style backlighting for extremely long life.
- A simple balancing scheme using a [ZERO] key.
- Up to 81 different batching recipes (EZ 320).
- Three recipe entry modes Percent of total, Pounds per animal, or Pounds per Ingredient (EZ 320).

OPERATING SPECIFICATIONS:

Accuracy	System \pm .25% or \pm .5% depending on load cell used
Temperature Range	
Power Requirements	10½ - 16 VDC

Turning_ON_the_Scale:



A brief message is displayed (such as "*HELLO*"). The scale enters the GROSS weighing mode. Pressing [ON] a second time during normal system operation starts the self test.

A *warm up period* of ten to fifteen minutes provides the most accurate readings. If the scale is holding a load for a long period of time (ex. overnight), the weight displayed may vary because of *zero shift* created by changes in temperature. This <u>does not</u> affect the accuracy of the scale.

For example, if the system was loaded with 1000Lbs, it might read 1200Lbs the following day. The change in temperature *"zero shifted"* the ZERO/BALANCE from 0Lbs to 200Lbs. When unloading the scale, the display will count from 1200 to 200Lbs for a total of 1000Lbs.

Turning_OFF_the_Scale:

Step 1) Press [OFF]. Off

To_Zero-Balance_the_Scale:

Step 1) Press the [NET/GROSS] key and within three seconds,

Step 2) press the [ZERO] key.



The **ZERO/BALANCE** will "balance off" the dead load such as a trailer, bin, or platform weight.

"ZERO" is displayed to show completion of the step and the scale is then placed in the GROSS mode.

Pressing <u>only</u> the [ZERO] key causes the message "TO ZERO/BALANCE PRESS NET/GROSS - THEN ZERO" to be displayed. If the supply power is below the "low battery threshold" (10.5 Volts), the message "INDICATOR CANNOT BE ZE-RO/BALANCED - LOW BATTERY VOLT-AGE" is displayed. The message "LO BAT" will be periodically shown on the display (approx. every five seconds) to alert the operator of the low battery condition. GROSS mode displays the weight change since the unit was last ZERO/BALANCED.

Step 1) Press [NET/GROSS].



NOTE: The scale is in GROSS mode if there is a flashing arrow pointing toward the GROSS text just above the [NET/GROSS] key.

To_Select_Net_Mode:

NET mode displays the weight change after a TARE has been performed. TARE is a <u>temporary</u> "zero" point.

Step 1) If the scale "TARE" weight has not been entered, press [TARE] to acquire a "zero".



[NET/GROSS]. The [NET/GROSS] key is an alternating action key. If the scale is in the GROSS mode, pressing the [NET/GROSS] key places it in the NET mode. If the scale is in the NET mode, pressing the [NET/GROSS] key places it in the GROSS mode.

If the "TARE" function has not been performed, the unit stays in the Gross mode and the message *"FOR NET MODE PRESS TARE"* scrolls across the display.

NOTE: The scale is in NET mode if a flashing arrow points to the NET text just above the [TARE] key.

MODEL 150 - *Optional Features:* W4444444444444444

Remote_Display_Option: A Remote Display is available for viewing weights at convenient locations. The Remote Display includes a visual alarm light which can be used with the TR option listed below.

TR_Option:_Radio_Control The TR option allows the operator to remotely control the scale from a distance up to 100 feet away.

The TR option allows the operator to perform TARE and GROSS functions.

Contact J-Star or your J-Star Dealer for additional options.

or

Step 2) If in Gross mode, press

The indicator is easily attached to the Indicator Mounting Bracket by hooking the top over the plate and securing the bottom with two (2) screws (size $\#10-24 \times 5/8"$) and nuts.

Power Connection:

Warning!

Always disconnect the indicator power cord <u>before</u> "jump starting" or fast charging a battery. Disconnect <u>all</u> indicator leads before welding on equipment. Failure to do so can cause surges which will damage the scale.

The power cable should be connected directly to a vehicle battery or regulated power supply. The scale end of the power cable is attached to the **J901** connector located on the bottom panel of the scale.

Connect the **RED** wire from the power cable to +12 VDC and the **BLACK** wire to **GROUND**. The indicator is fused internally at 4 amps.

POWER CABLE CONNECTIONS:

2)

INDICATOR BOTTOM PANEL CABLE CONNECTIONS:



Load Cell Connection:

The indicator is designed to operate with strain gage load cells. The system is normally supplied with a *"J-BOX"* cable going between the scale and the load cell junction box. Extension Kits are available from your dealer in various lengths.

To connect the load cells, attach the junction box cable to the **J902** connector on the bottom panel of the scale. Connect the load cell cables to the junction box as shown below.

Lightning Protection:

Additional protection is achieved with the proper installation of grounding rods. Please call (920) 563-1400 and request Digi-Star Form F3050.

JUNCTION BOX LOAD CELL CABLE CONNECTIONS:



_	TERMINAL COLOR	DESCRIPTION
	WHITE	SIGNAL +
	GREEN	SIGNAL -
	RED	EXCITATION +
	BLAÇK	EXCITATION -
	SHIELD	SHIELD

NOTE: Follow color key on circuit board to insure proper connection of load cell wires.

MODEL 210 - System Operation: Turning ON the Scale:

Step 1) Press [ON]. On \cap O On 110 Zero 2 3 1 5 6 4 8 9 Load or Unicad Net Tare 0 Help Gross 1571 EZ 210 0 0

A brief message will be displayed (such as "HELLO"). The scale then selects the GROSS weighing mode. Pressing [ON] a second time during normal system operation starts the self test.

A *warm up period* of ten to fifteen minutes provides the most accurate readings. If the scale is holding a load for a long period of time (ex. overnight), the weight displayed may vary because of *zero shift* created by changes in temperature. This does not affect the accuracy of the scale.

For example, if the system was loaded with 1000Lbs, it might read 1200Lbs the following day. The change in temperature "zero shifted" the ZERO/BALANCE from 0Lbs to 200Lbs. When unloading the scale, the display will count from 1200 to 200Lbs for a total of 1000Lbs.

Turning_OFF_the_Scale:



To Zero-Balance_the_Scale:

Step 1) Press the [NET/GROSS] key and within three seconds.

Step 2) press the [ZERO] key.



The **ZERO/BALANCE** will "balance off" trailer, bin, or platform weight.

"ZERO" is displayed to show completion of the step and the scale is then placed in the GROSS mode.

Pressing only the [ZERO] key causes the message "TO ZERO/BALANCE PRESS NET/GROSS - THEN ZERO" to be displayed. If the supply power is below the "low battery threshold" (10.5 Volts), the message "INDÍCATOR CANNOT BE ZE-RO/BALANCED - LOW BATTERY VOLT-AGE" is displayed. The message "LO BAT" is periodically shown on the display (approx. every five seconds) to alert the operator of the low battery condition.

Loss of power **does not** affect the "setup/calibration" values.

Using_the_Help_Key:

The [HELP] key provides additional information about the weighing modes, setup/calibration, and keypad entries.

Step 1) Pressing [HELP] while displaying weight will display information about the last key pressed.



To_Select_Gross_Mode:

GROSS mode displays the weight change since the unit was last ZERO/BALANCED.

Step 1) Press [NET/GROSS].



Net	
Gross	

Press the [NET/GROSS] key if in the NET or LOAD/UNLOAD mode.

NOTE: The scale is in GROSS mode if there is a flashing arrow pointing toward the GROSS text above the [NET/GROSS] key.

To_Select_Net_Mode:

NET mode displays the weight change after a TARE has been performed. TARE is a <u>temporary</u> "zero" point.

Step 1) If the scale "TARE" weight has not been entered, press [TARE] to acquire a "zero".



or

Step 2) If in Gross mode, press [NET/GROSS]. The [NET/GROSS] key is an alternating action key. If the scale is in the GROSS mode, pressing the [NET/GROSS] key will place it in the NET mode. If the scale is in the NET mode, pressing the [NET/GROSS] key will place it in the GROSS mode. If in LOAD-UNLOAD mode, press [NET/GROSS] two (2) times.

If the "TARE" function has not been previously performed, the unit stays in the Gross mode and the message *"FOR NET MODE PRESS TARE"* will scroll across the display.

NOTE: The scale is in NET mode if there is a flashing arrow pointing toward the NET text just above the [TARE] key.

To_Enter_a_Preset:

A "preset" is a weight amount that can be set in the scale. The scale will activate alarms once that weight amount has been either removed or added.

Step 1) Use the numeric keypad to enter the desired preset weight value.

Step 2) Press either [NET/GROSS] or [LOAD/UNLOAD] to enter the preset value and select the *"display mode"*.

The 'PRESET' annunciator outer triangle turns ON when the preset amount is entered.



Once the preset has been entered, the display shows the weight data in one of three (3) different *"display modes"*.

The three display modes are:

"GROSS MODE"

The gross weight is displayed by pressing the [NET/GROSS] key. As ingredients are loaded, the weight display counts upward toward the preset value. As ingredients are unloaded the weight display counts down to the preset value.

"LOAD/UNLOAD MODE"

Press the [LOAD/UNLOAD] key to display the amount remaining to be loaded or unloaded. As ingredients are loaded <u>OR</u> unloaded, the display counts down from the entered preset weight until it reaches zero.

"NET MODE"

The weight added since the preset has been entered is displayed by pressing the [NET/GROSS] key two (2) times if in the LOAD/UNLOAD MODE, one (1) time if in the GROSS MODE. As ingredients are loaded, the weight display counts upward, as they are unloaded the weight display counts down.

Switching between these display modes is possible at any time by simply pushing the appropriate keys.

Before the preset weight is reached, the **pre-alarm** is activated. This causes the preset display annunciator, the front panel alarm light, the output relay, and the alarm horn all to pulse in sequence with the alarm light. Set the pre-alarm value to "0" to prevent the alarm output from pulsing.

When the preset weight is reached, the front panel alarm light, the output relay, the 'PRESET' annunciator, and the alarm horn will all be held ON.

To Clear the Preset & Alarm:

Step 1) Press the [CLEAR] key.



At this time, a new preset can be entered or by pressing the [CLEAR] key a second time (with a flashing zero " 0" shown on the display) the scale will return to weighing.

Reloading a preset value with the "REMOTE ENTER PRESET" line of the power cord will also clear the previous preset condition.

Using the "REMOTE ZERO" feature of the 20R TR option also clears the previous preset condition.

To Preload a Tare Value:

The scale also allows the "tare weight" to be entered via the numeric keypad. This is performed by entering the weight value on the keypad and then by pressing the [TARE] key.



The preload tare feature is useful for weighing containers after they have already been loaded. If the weight of the container is known, this *"tare weight"* could be preloaded into the scale and the net weight will be displayed. The *"tare weight"* is also sent to the printer.

An example could be demonstrated with a feed wagon on a platform scale:

- Step 1 Balance the scale.
- Step 2 Weigh and record the weight of the unloaded wagon.
- Step 3 Pull the wagon off the scale and load.
- Step 4 Enter the wagon's tare weight.
- Step 5 Place loaded wagon back on the scale to see net weight.

Note: This feature can be turned ON or OFF with the Preload Tare {PRETAR} setting in the Long Form Setup.

Using_the_Pre-Alarm:

The Pre-Alarm feature is an "early warning" for the preset. For example, if the Pre-Alarm is set to 100 and the preset is 1000, the preset alarms will flash during the last 100 lbs/kgs of the preset. The alarms are continuous once the preset is active. This allows more accuracy in *reaching the preset*.

Change_the_Pre-Alarm_Weight:

Step 1) Press and hold the [NET/GROSS] key, then press the [ON] key. Continue holding both keys until the indicator beeps and displays the message "*P-ALM*". The 'CAL' annunciator flashes and the current pre-alarm weight is displayed.



Step 2) Press the [CLEAR] key to erase the current weight value.



Step 3) Use the numeric keypad to select a pre-alarm weight.



Step 4) Press the [ON] key. The display advances to the next setup value.

Step 5) To exit setup and return to weighing, press and hold the [TARE] key, then press the [ON] key.



The indicator is easily attached to the Indicator Mounting Bracket by hooking the top over the plate and securing the bottom with two (2) screws (size $\#10-24 \times 5/8"$) and nuts.

Power Connection:

Warning!

Always disconnect the indicator power cord <u>before</u> ''jump starting'' or fast charging a battery. Disconnect <u>all</u> indicator leads before welding on equipment. Failure to do so can cause surges which will damage the scale.

The power cable should be connected directly to a vehicle battery or regulated power supply. The scale end of the power cable is attached to the **J901** connector located on the bottom panel of the scale.

Connect the **RED** wire from the power cable to +12 VDC and the **BLACK** wire to **GROUND**. The indicator is fused internally at 4 amps.

POWER CABLE CONNECTIONS:

WIRE COLOR	WIRE FUNCTION
RED	Battery(+12 VDC)
BLACK	GROUND
ORANGE	Remote Alarm Out +
BLUE	Remote Input
	-

Remote Alarm Connection:

If a remote 12 VDC alarm is to be used, connect the +12 VDC side of the alarm to the power cable orange wire and the GROUND side of the alarm to **INDICATOR BOTTOM PANEL CABLE CONNECTIONS:**



the frame. The alarm output is fused for a maximum drain of 10 amps. The remote alarm connection may also be used for motor control purposes when used with a relay.

Remote Input Connection:

If the remote input is to be used, connect one side of the normally open momentary switch or relay contact to the power cable blue wire, and the other side to the frame or other GROUND connection. If your power cable does not contain a blue wire and you desire to use this feature, contact your dealer for a special cable. A process control box is available for motor control and remote *enter preset* capability.

Load Cell Connection:

The indicator operates with strain gage load cells. The system is normally supplied with a *"J-BOX"* cable going between the scale and the load cell junction box. Extension Kits are available from your dealer in various lengths.

Attach the junction box cable to the **J902** connector on the bottom panel of the scale. Connect the load cell cables to the junction box as shown below.

Lightning Protection:

Additional protection is achieved with the proper installation of grounding rods. Please call (414) 563-5521 and request J-Star Form F3050.

JUNCTION BOX LOAD CELL CABLE CONNECTIONS:



_	TERMINAL COLOR	DESCRIPTION
	WHITE	SIGNAL +
	GREEN	SIGNAL -
	RED	EXCITATION +
	BLACK	EXCITATION -
	SHIELD	SHIELD

NOTE. Follow color key on circuit board to insure proper connection of load cell wires.

Remote_Display:

A Remote Display is available for viewing weights at convenient locations. The Remote Display includes a visual alarm light which can be used with the TR4 option listed below.

TR-TR4:_Radio_Control

The TR and TR4 options allow the operator to remotely control the scale from a distance up to 100 feet away.

The **TR** option allows the operator to perform TARE and GROSS functions.

The **TR4** option allows remote operation of the RM (recall memory), M+ (memory plus), TARE, and either NET/GROSS or CM (clear memory). To Print:

Scale data can be sent to a printer by pressing the [PRINT] key.



An auto-print feature is implemented on the TR and TR4 options.

Sample output format shown below:

+))))))))))))))))))))))))))))))))))))))						
*		10J <i>I</i>	492	12:01	P	*
*	123456	ID	123	456LB	GR	*
.)))))))))))))))))))))))))))))))-	

"Clock" & "ID #" options also shown.

Enter_Identification_Number:ID#

Step 1) Use the numeric keypad to select the identification number.

Step 2) Press the [ID #] key to enter the identification number.



Display_Identification_Number:

Step 1) Press the [ID #] key.



The identification number is cleared by pressing the [CLEAR] key followed by pressing the [ID #] key. NOTE: Printing automatically clears the identification number. Add_Weight_To_Weigh_Memory:

The displayed weight is stored in memory by pressing the [M+] (memory plus) key.



The weigh memory is temporarily displayed.

If a weight was previously stored in memory, the displayed weight is added to weigh memory.

Recall_Weigh_Memory:

The value of total weight in memory can be displayed by pressing the [RM] (recall memory) key.



The weigh memory is temporarily displayed.

Print_Weigh_Memory:

The value of total weight in memory can be printed by pressing the [RM] (recall memory) key and then the [PRINT] key *while the weigh memory is still displayed*.



The [PRINT] key causes the unit to return to the normal weighing modes.

Clear_Weigh_Memory:

The weigh memory is cleared by pressing the [CLEAR] key followed by pressing the [RM] key.



Black_Out:

The Black Out option is a preset enhancement that maintains the "*Preset amount left to go*" in *non-volatile*, permanent memory. This insures that the correct weight can be delivered *even* after a power outage.

For example, a system loaded with 2000Lbs was unloading a preset of 1000Lbs. After unloading the first 500Lbs, a power outage occurred. When the power returned and the scale was turned ON, the message "POWER OUTAGE - PRESS START ON CONTROL BOX TO FINISH PRESET - CLEAR TO CANCEL MO/DA/YR 12:00A" appeared.

Pressing START on the Control Box (or the [NET/GROSS] key on the scale) loads the preset amount remaining <u>before</u> the black out (500Lbs in this case).

Pressing the [CLEAR] key cancels the preset and the scale displays the GROSS weight.

The *Clock* option is required as part of the *Black Out* option. The *Clock* records the time, date, and preset remaining before the power outage (blackout).

Pulsed_Output:

The Pulsed Output option provides one (1) output line to indicate decreasing weight.

Pulsed Output pulls the connected signal line to ground through a 330 Ohm resistor for 150 milli-seconds every time the scale decreases one (1) display count.

1 Display Count = 1 Output Pulse The scale will not pull the line to ground more than twice (2 times) a second - **2 Hz**. For example, if the weight decreased from 8000 lbs. to 7500 lbs. using a display count of 10 lb counts.

8000 - 7500 = 500 (Lbs weight change) 500 / 10 (Display Count) = 50 (Pulses)

There would be 50 output pulses taking

about 25 seconds to output all 50 pulses.

In this example, 7500Lbs represents the "GROSS weight reference point". The scale resets the "GROSS weight reference point" if the weight increases 100 or more pounds for at least one (1) minute. The scale starts pulsing outputs as weight decreases from the new "GROSS weight reference point".

There are two (2) ways to "reset" or "abort" the internal pulse counter of the scale;

1 - ZERO/BALANCE the scale,

or 2 - Turn the scale "OFF" and then "ON" again and press "ZERO" when the scale shows the power outage message.

The *Clock* option is required as part of the *Pulsed Output* option. The *Clock* records the time, date, and "*GROSS weight reference point*" before the power outage (blackout).

When the scale power is returned and the scale is turned back *ON* after a power loss, the scale will display the message - *"POWER OUTAGE - PRESS NET/GROSS TO CONTINUE PULSED OUTPUT - ZERO TO RESET MO/DA/YR 12:00A"*. This provides the opportunity to start other equipment in the proper sequence.



A brief message is displayed (such as *"HELLO"*). The scale then selects the GROSS weighing mode.Pressing [ON] a second time during normal system operation starts the self test.

A *warm up period* of ten to fifteen minutes provides the most accurate readings. If the scale is holding a load for a long period of time (ex. overnight), the weight displayed may vary because of *zero shift* created by changes in temperature. This <u>does not</u> affect the accuracy of the scale.

For example, if the system was loaded with 1000Lbs, it might read 1200Lbs the following day. The change in temperature *"zero shifted"* the ZERO/BALANCE from 0Lbs to 200Lbs. When unloading the scale, the display will count from 1200 to 200Lbs for a total of 1000Lbs.

Turning_OFF_the_Scale:

Step 1) Press [OFF].





To_Zero-Balance_the_Scale:

Step 1) Press the [NET/GROSS] key and within three seconds,

Step 2) press the [ZERO] key.



The **ZERO/BALANCE** will "balance off" trailer, bin, or platform weight.

"ZERO" is displayed to show completion of the step and the scale is then placed in the GROSS mode.

Pressing <u>only</u> the [ZERO] key will cause the message "TO ZERO/BALANCE PRESS NET/GROSS - THEN ZERO" to be displayed If the supply power is below the "low battery threshold" (10.5 Volts), the message "INDICATOR CANNOT BE ZE-RO/BALANCED - LOW BATTERY VOLT-AGE" is displayed. The message "LO BAT" is periodically shown on the display (approx. every five seconds) to alert the operator of the low battery condition.

Loss of power **does not** affect the "*set-up/calibration*" values.

Using_the_Help_Key:

The [HELP] key provides additional information about the weighing modes, setup/calibration, and recipe programming.

Step 1) Pressing [HELP] while displaying weight will display information about the last key pressed.



To_Select_Gross_Mode:

GROSS mode displays the weight change since the unit was last ZERO/BALANCED.

Step 1) Press [NET/GROSS].



Net	
Gross	,

Press the [NET/GROSS] key if in the NET or LOAD/UNLOAD mode.

NOTE: The scale is in GROSS mode if there is a flashing arrow pointing toward the GROSS text above the [NET/GROSS] key.

To_Select_Net_Mode:

NET mode displays the weight change after a TARE has been performed. TARE is a <u>temporary</u> "zero" point.

Step 1) If the scale "TARE" weight has not been entered, press [TARE] to acquire a "zero".

Program Timer Zero On Off Program Motion Preset
Print 1 2 3 U. 4 5 6
Not Load Gross Tare Load Meters Tare Load Net Net Ingr. Clear O Help
FSTAR EZ 320 Scale indicator
Tare

or

Step 2) If in Gross mode, press [NET/GROSS]. The [NET/GROSS] key is an alternating action key. If the scale is in the GROSS mode, pressing the [NET/GROSS] key places it in the NET mode. If the scale is in the NET mode, pressing the [NET/GROSS] key places it in the GROSS mode. If in LOAD-UNLOAD mode, press [NET/GROSS] two (2) times.

If the "TARE" function has not been previously performed, the unit will stay in the Gross mode and the message "FOR NET MODE PRESS TARE" scrolls across the display.

NOTE: The scale is in NET mode if there is a flashing arrow pointing toward the NET text just above the [TARE] key.

To_Enter_a_Preset:

A "preset" is a weight amount that can be set in the scale. The scale will activate alarms once that weight amount has been either removed or added.

Step 1) Use the numeric keypad to enter the desired preset weight value.

Step 2) Press either [NET/GROSS] or [LOAD/UNLOAD] to enter the preset value and select the "*display mode*".

The 'PRESET' annunciator outer triangle will turn ON when the preset amount is entered.



Once the preset has been entered, the display shows the weight data in one of three(3) different "*display modes*".

The three display modes are:

"GROSS MODE"

The gross weight is displayed by pressing the [NET/GROSS] key. As ingredients are loaded, the weight display counts upward toward the preset value. As ingredients are unloaded the weight display counts down to the preset value.

"LOAD/UNLOAD MODE"

Press the [LOAD/UNLOAD] key to display the amount remaining to be loaded or unloaded. As ingredients are loaded <u>OR</u> unloaded, the display counts down from the entered preset weight until it reaches zero.

"NET MODE"

The weight added since the preset has been entered is displayed by pressing the [NET/GROSS] key two (2) times if in the LOAD/UNLOAD MODE, one (1) time if in the GROSS MODE. As ingredients are loaded, the weight display counts upward, as they are unloaded the weight display counts down.

Switching between these display modes is possible at any time by simply pushing the appropriate keys.

Before the preset weight is reached, the **pre-alarm** is activated. This causes the preset display annunciator, the front panel alarm light, the output relay, and the alarm horn all to pulse in sequence with the alarm light. Set the pre-alarm value to "0" to prevent the alarm output from pulsing. See page 21 for more information.

When the preset weight is reached, the front panel alarm light, the output relay, the 'PRESET' annunciator, and the alarm horn will all be held ON. Step 1) Press the [CLEAR] key twice.



This sets the display to zero's " 0" and returns the scale to weighing.

By pressing the [CLEAR] key only once, a new preset can be entered.

The current preset alarm condition is also cleared if *reloading* a preset using the "REMOTE ENTER PRESET" feature. This feature is selected by setting **Remote Input** to 'PRESET' in the *Long Form Setup*. It is activated by using the 20R TR option or by momentarily connecting the "REMOTE" line in the power cord to +12 Volts DC.

Using the "REMOTE ZERO" feature of the 20R TR option or "REMOTE" line in the power cord also clear the preset.

To_Preload_a_Tare_Value:

The scale also allows the "tare weight" to be entered via the numeric keypad. This is performed by entering the weight value on the keypad and then by pressing the [TARE] key.



The preload tare feature is useful for weighing containers after they have already been loaded. If the weight of the container is known, this *"tare weight"* is preloaded into the scale and the net weight is be displayed. The *"tare weight"* is also sent to the printer.

The following example demonstrates a feed wagon on a platform scale:

- Step 1 Balance the scale.
- Step 2 Weigh and record the weight of the unloaded wagon.
- Step 3 Pull the wagon off the scale and load.
- Step 4 Enter the wagon's tare weight.
- Step 5 Place loaded wagon back on the scale to see net weight.

Using_the_Pre-Alarm:

The Pre-Alarm feature is an "early warning" for the preset. For example, if the Pre-Alarm is set to 100 and the preset is 1000, the preset alarms flash during the last 100 lbs/kgs of the preset. The alarms are continuous once the preset is active. This allows more accuracy in reaching the preset.

Changing_Pre-Alarm_Weight:

Step 1) Press and hold the [NET/GROSS] key, then press the [ON] key. Continue holding both keys until the indicator beeps and displays the message "P-ALM". The 'CAL' annunciator flashes and the current pre-alarm weight is displayed.



Step 2) Press the [CLEAR] key to wrase the current weight value.







Step 4) Press the [ON] key. The display will advance to the next setup value.

Step 5) To exit setup and return to weighing, press and hold the [TARE] key, then press the [ON] key.



To_Start_the_Mix_Timer:

There are two ways to start the Mix Timer.

Step 1) Press the [TIMER] key to see the time currently set. The [NET/GROSS] and [TARE] keys can then be used to change the displayed value.

The [NET/GROSS] key increments the "flashing" digit and the [TARE] key selects which digit of the display is flashing.

When the correct time has been entered or if the number displayed is acceptable, press the [TIMER] key to set the time and start the Mix Timer.

or

Step 2) Use the numeric keypad to select the amount of time. Then press the [TIMER] key to enter the time.





The display now reads HOURS, MINUTES, and SECONDS (HH:MM:SS), separated by colons that flash every second.



To_Clear_the_Mix_Timer:

Step 1) Press either the [CLEAR] or [TIMER] key. The scale clears the mix timer alarms and enters the weighing mode.



To_Re-Start_the_Mix_Timer:

Step 1) Press the [TIMER] key twice (2) without entering a numeric value to start the mix timer using the time previously entered.

Entry_Methods:

There are three(3) different methods for programming recipes:

- Entry Method
- 1 Amount per Animal
- 2 Percent(%) per Load
- 3 Amount per Load

NOTE: Recipes programmed in one method will not be converted if a new entry method is selected. To convert a recipe to a new method, erase and then re-program the recipe.

Entry Method #1 - Amount per Animal.

Program the ingredient amounts required for feeding one(1) animal. When recipe is loaded and indicator flashes "ANIMAL", enter the number of animals to be fed. The scale calculates the preset amounts required for each ingredient.

Example: A recipe had been programmed with 18Lbs of haylage and 16Lbs of shell corn for one(1) animal. The recipe was then loaded for 100 "ANIMAL"s. The scale calculated presets for 1800Lbs of haylage and 1600Lbs of shell corn.

Entry Method #2 - Percent(%) per Load/Animal. Program the ingredient amounts in percentages(%). When recipe is loaded and indicator flashes "TOTAMT", enter the total amount to be loaded. The scale calculates the preset amounts required for each ingredient.

Example: A recipe had been programmed with 55% of haylage and 45% of shell corn. The recipe was then loaded for a *"TOTAMT"* of 10,000Lbs. The scale calculated presets for 5500Lbs of haylage and 4500Lbs of shell corn.

Entry Method #3 - Amount per Load.

Program the ingredient amounts required per load. When recipe is loaded and indicator flashes "TOTAMT", the **total amount programmed for that recipe** is displayed. Press [LOAD/UNLOAD] to accept that amount <u>or</u> enter a new total amount and the scale calculates new preset amounts.

Example: A recipe had been programmed with 5500Lbs of haylage and 4500Lbs of shell corn. The recipe was then loaded for a *"TOTAMT"* of 10,000Lbs. The scale calculated presets for 5500Lbs of haylage and 4500Lbs of shell corn.

This same recipe could have been changed the *"TOTAMT"* to 9,000Lbs and the scale would have calculated presets for 4950Lbs haylage and 4050Lbs shell corn.

To_Change_the_Entry_Method:

Step 1) Enter the "Long Form Setup Mode" by press and holding the [NET/GROSS] key and then pressing the [ON] key. Continue holding both keys until the indicator beeps and the scale displays the message "*P*-*ALM*".



The "CAL" annunciator will be flashing. Press the [ON] key until "*E MTHD*" is displayed.

To select the recipe entry method.

Step 2) Press [NET/GROSS] until the correct number is displayed.



- Entry Method
- 1 Amount per Animal
- 2 Percent(%) per Load
- 3 Amount per Load

Step 3) Press the [ON] key. The display advances to the next setup value.

Step 4) To exit setup and return to weighing, press and hold the [TARE] key, then press the [ON] key.



These examples are shown to illustrate the three different program entry methods available. Each method can be used to obtain the same results, the choice is yours. Note that Recipe #5 includes some of the same ingredients as Recipe #12, but are loaded in a different sequence to illustrate the flexibility of programming to match actual loading sequence.

To Program						
PROGRAM ENTRY METHODS AVAILABLE RECIPE #12 (CHOOSE ONE)					LABLE	
INGREDIENT NAME	INGREDIENT NUMBER	AMT. PER ANIMAL		% PER LOAD		AMOUNT PER LOAD
(1) Haylage	3	18.0	0	34.62		1800
(2) High Moisture Corn	9	10.0	R	19.23	R	1000
(3) Corn Silage	5	24.0		46.15		2400
	Total	52 Lbs		100.00		5200

To Load							
		AMT. PER ANIMAL		% PER LOAD		AMOUNT PER LOAD	
RECIPE #12		ENTER # OF ANIMALS		ENTER LOAD SIZE		ACCEPT 5200 OR ENTER NEW SIZE	
INGREDIENT NAME	INGREDIENT NUMBER	⇒100 ANIMALS	O R	⇒ 5200	O R	⇒ 5200	
(1) Haylage	3	1800		1800		1800	
(2) High Moisture Corn	9	1000		1000		1000	
(3) Corn Silage	5	2400		2400		2400	
Total		5200		5200		5200	

To Program						
PROGRAM ENTRY METHODS AVAILABLE RECIPE #5 (CHOOSE ONE)				LABLE		
INGREDIENT NAME	INGREDIENT NUMBER	AMT. PER ANIMAL		% PER LOAD		AMOUNT PER LOAD
(1) Corn Silage	5	15.0		37.5		1800
(2) Haylage	3	14.5	0	36.25	0	1740
(3) Soy Bean	10	2.3	R	5.75	R	276
(4) Cotton Seed Hulls	12	8.2		20.50		984
	Total	40 Lbs		100.00		4800







To Load						
		AMT. PER ANIMAL		% PER LOAD		AMOUNT PER LOAD
RECIPE #5		ENTER # OF ANIMALS		ENTER LOAD SIZE		ACCEPT 4800 OR ENTER NEW SIZE
INGREDIENT NAME	INGREDIENT NUMBER	⇒120 ANIMALS	ο	⇒ 4800	о	⇒ 4800
(1) Corn Silage	5	1800	R	1800	R	1800
(2) Haylage	3	1740		1740		1740
(3) Soy Bean	10	276		276		276
(4) Cotton Seed Hulls	12	984		984		984
	4800		4800		4800	

1: Amount per Animal -Recipe amounts programmed for 1 animal.



Ingredient presets for a 100 animal

load.		
1 Local	 - 40 1	h

Haylage	= 18 LDS
Corn Silage	= 10 Lbs
HM Shell Corn	= 16 Lbs
Soy Hulls	= 02 Lbs
Soybeans	= 06 Lbs

TOTAL = 52 Lbs

2: Percent per Load - %

Recipe amounts programmed in % for Total Load.

Haylage	=	34.60 %
Corn Silage	=	19.23 %
HM Shell Corn	=	30.77 %
Soy Hulls	=	03.85 %
Soybeans	=	11.55 %

TOTAL = 100.00 %

3: Amount per Load - Lbs

Recipe amount programmed in Total Lbs/Load.

Haylage	= 1800 Lbs
Corn Silage	= 1000 Lbs
HM Shell Corn	= 1600 Lbs
Soy Hulls	= 200 Lbs
Soybeans	= 600 Lbs

TOTAL = 5200 Lbs

X 100	Haylage	= 1800 Lbs
	Corn Silage	= 1000 Lbs
	HM Shell Corn	= 1600 Lbs
	Soy Hulls	= 200 Lbs
	Soybeans	= 600 Lbs

TOTAL = 5200 Lbs

Ingredient presets for 5200 lb load.

Haylage	= 1800 Lbs
Corn Silage	= 1000 Lbs
HM Shell Corn	= 1600 Lbs
Soy Hulls	= 200 Lbs
Soybeans	= 600 Lbs

TOTAL = 5200 Lbs

Ingredient presets for 5200 lb load.

Haylage	= 1800 Lbs
Corn Silage	= 1000 Lbs
HM Shell Corn	= 1600 Lbs
Soy Hulls	= 200 Lbs
Soybeans	= 600 Lbs

TOTAL = 5200 Lbs

Enter the program mode by press and holding the [PROGRAM] key and then pressing the [ON] key. Continue holding both keys until the indicator beeps and the scale displays the message "PROGRM". The "recipe program annunciator" flashes.



The scale then displays the first formula number programmed "*REC-XX*" or will display "*REC-__*" indicating that a recipe number can be entered.



Step 2) Then use the numeric keypad to select the recipe number. Then press [RECIPE #] to enter the recipe number.

Step 3) The EZ 320 then displays a message indicating the "entry method" to be used:

- 1 Pounds per Animal.
- 2 Percentage of Total Load.
- 3 Ingredient in Pounds.

Note: For more about entry methods see page 23.

Step 4) "*ING*-___" is displayed immediately following the entry message.

Use the numeric keypad to select the ingredient number. Then press [INGR.#]. NOTE:Ingredient numbers <u>DO NOT</u> have to be in sequence.

Step 5) "AMOUNT" will be shown on the display followed by the prompt for the ingredient amount with the display "YY:XXXX".

The first two digits, "YY" represent the ingredient number. The last four digits, "XXXX" represent the amount for this ingredient.

In this example, ingredient number "05" is shown with an ingredient amount of "500".

Use the numeric keypad to select the four (4) digit ingredient value. Then press [LOAD/UNLOAD] to enter the value.

Step 6) The scale will display the message "*STORED*" indicating that the ingredient has been saved into *non-volatile memory*.

Step 7) Continue steps 4 through 6 until all ingredients have been entered.

Step 8) Press [RECIPE#] to complete the recipe. The scale will now calculate and display the *"TOTAL"* value of the recipe.

Step 9) Repeat steps 1 through 8 until all recipes have been entered.

Step 10) Press [PROGRAM] to exit the *"recipe programming mode"* and enter the weighing modes.

To_Edit_a_Recipe:

Enter the program mode by press and holding the [PROGRAM] key and then pressing the [ON] key. Continue holding both keys until the indicator beeps and the scale displays the message "PROGRM". The "recipe program annunciator" will be flashing.

The scale then displays the first formula number programmed "REC-XX". Use one of the following methods to select the recipe to edit:

Method 1:

Step 1) Press [RECIPE#] until the desired recipe number is displayed.

Step 2) Then press [INGR#] to edit this recipe. Now go to Step 4.

Method 2:

Step 3) Then use the numeric keypad to select the recipe number. Then press [RECIPE #] to enter the recipe number or press [RECIPE#] to advance until the desired recipe is displayed.

Step 4) The EZ 320 will then display a message indicating the "entry method" to be used:

- 1 Pounds per Animal.
- 2 Percentage of Total Load.
- 3 Ingredient in Pounds.

Step 5) The ingredient number and amount will be displayed "YY:XXXX".

The first two digits, "YY" represent the ingredient number. The last four digits, "XXXX" represent the amount for this ingredient.

Step 6) Pressing [INGR.#] will advance the scale to the next ingredient of the recipe. Press [INGR.#] until the desired ingredient is displayed. Step 7) Press [CLEAR] and then use the numeric keypad to select the four (4) digit ingredient value. Press [LOAD/UNLOAD] to enter the value.

Step 8) The scale will display the message "STORED" indicating that the ingredient has been saved into *non-volatile memory*. Non-volatile memory is a special type of memory that allows the power to be removed from the scale without losing the any of the recipes.

Step 9) Continue steps 5 through 8 until the desired changes have been made.

Step 10) Press [RECIPE#] to complete the recipe. The scale will now calculate and display the "TOTAL" value of the recipe.

Step 11) Press [PROGRAM] to exit the "recipe programming mode" and enter the weighing modes.

NOTE: Ingredient amounts

To_Erase_a_Recipe:

Enter the program mode by press and holding the [PROGRAM] key and then pressing the [ON] key. Continue holding both keys until the indicator beeps and the scale displays the message "*PROGRM*". The "recipe program annunciator" will be flashing.

The scale then displays the first formula number programmed "*REC-XX*". Use one of the following methods to select the recipe to erase:

Method 1:

Step 1) Press [RECIPE#] until the desired recipe number is displayed, then go to Step 3.

Method 2:

Step 3) Press the [ZERO] key.

Zero

Step 4) Press and hold the [ZERO] key, then press the [ON] key to erase the recipe. Continue holding both keys until the indicator beeps and displays the message "*RECIPE XX ERASED*".

Step 5) Press [PROGRAM] to exit the *"recipe programming mode"* and enter the weighing modes.

To erase all recipes, Continue steps 1 through 4 until the all recipes have been erased.

Clear Step 1) Press [CLEAR].

Step 2) Then use the numeric keypad to identify the recipe number to be erased.

Using_the_Auto_Advance_Feature:

The auto advance feature allows for *hands free* operation of programmed recipes. The indicator prints and advances to the next ingredient once the *motion*, *tolerance*, and *delay time* requirements have been met.

Using_Tolerance:

The Tolerance feature is a "tolerance window" for the preset ingredient during batching. For example, if the tolerance is set to 5(%) and the preset is 1000, the "tolerance window" is ± 50 . So the scale is in the "tolerance window" when the display is between 50 and -50.

The auto-advance circuitry of the recipe function activates the "delay time" counter while the weight is in the "tolerance window". The alarms sound continuous at this time and the preset is considered active. This allows the operator to slightly "under or over shoot" an ingredient amount and still automatically advance to the next ingredient. The autoadvance circuitry resets the "delay time" counter everytime the weight moves out of the tolerance window. If enabled, "motion detection" also resets the "delay time" counter.

If the tolerance for that ingredient is exceeded, the message "*OVER*" is displayed alternately with the weight value. During this time the scale <u>WILL NOT</u> auto-advance. This allows the operator the opportunity to remove the excess weight. If the additional weight for the ingredient is acceptable, press either [PRINT] or [INGR.#] to advance to the next ingredient.

Setting tolerance to " *OFF*" allows the scale to <u>always</u> auto-advance after the ingredient amount has been loaded regardless of additional weight.

To_Change_the_Tolerance:

Step 1) Enter the "Long Form Setup Mode" by press and holding the [NET/GROSS] key and then pressing the [ON] key. Continue holding both keys until the indicator beeps and the scale displays the message "*P*-*ALM*" followed by the current pre-alarm weight. The "CAL" annunciator will be flashing.

Press the [ON] key until "TOLER" is displayed.

To select the amount (by percentage) that an ingredient can be under/over-loaded and still automatically advance,

Step 2) Press [NET/GROSS].

Set to " OFF " to <u>always advance</u> after the ingredient amount has been reached.

Tolerance Percentage Settings OFF, 0.5, 1, 2, 3, 4, 5, 7, or 10

Step 3) Press the [ON] key. The display will advance to the next setup value.

Step 4) To exit setup and return to weighing, press and hold the [TARE] key, then press the [ON] key.

Using_Delay_Time:

The Delay Time feature allows an operator to select the amount of time the scale should wait before automatically advancing to the next ingredient of the recipe. This helps insure accuracy for the ingredient amount. For example, if the delay time is set to 10(seconds) and the preset alarms are activated continuously, the auto-advance circuitry starts the "delay time" counter. If the preset de-activates, the delay time counter is reset, therefore assuring that the preset weight amount has to be met for the total delay time amount.

Setting Delay Time to "MANUAL" prevents the scale from <u>EVER</u> auto-advancing, regardless of the weight. Pressing either the [INGR.#] or [PRINT] key twice advances the recipe to the next ingredient. The first press completes the current ingredient and enters a "lock weight mode". This allows the scale system to be moved to a new location without affecting the weight amount of the next ingredient. The second press advances the scale recipe to the next ingredient.

After all ingredients have been loaded, the scale displays the message: "*RECIPE* COMPLETE TOTAL = XXXXXLB".

To_Change_the_Delay_Time:

Step 1) Enter the "Long Form Setup Mode" by press and holding the [NET/GROSS] key and then pressing the [ON] key. Continue holding both keys until the indicator beeps and the scale displays the message "*P-ALM*" followed by the current pre-alarm weight. The "CAL" annunciator will be flashing.

Press the [ON] key until the message "*DELAY*" is displayed.

To select the delay time (in seconds) to wait before automatically advancing,

Step 2) Press [NET/GROSS].

Net Gross

Set to "MANUAL" to <u>prevent advancing</u> after the ingredient amount has been reached.

Delay Ti	me S	electior	ns in Se	conds
MANUAL,	1, 2,	3, 5, 7,	10, 20,	30, or 60

Step 3) Press the [ON] key. The display will advance to the next setup value.

Step 4) To exit setup and return to weighing, press and hold the [TARE] key, then press the [ON] key.

Either of the following methods can be used to load a recipe while in the weighing modes:

Method 1:

Step 1) Press [RECIPE#] until the desired recipe number is displayed.

Step 2) Press [LOAD/UNLOAD] to accept the recipe. Go to Step 3.

Method 2:

Step 2) Then use the numeric keypad to select the recipe number. Then press [RECIPE#].

Step 3) The scale displays the message "LOADING RECIPE XX" and "TOTAMT". The message "TOTAMT" represents either the "total amount to be loaded" or the "total amount of animals" for that recipe.

To accept the total displayed, press [LOAD/UNLOAD].

or, To change the "TOTAMT" perform the following steps 4 and 5.

Step 4) Press [CLEAR].

Step 5) Then use the numeric keypad to enter a new total amount value. To accept the new total displayed, press [LOAD/UNLOAD]. *All ingredient amounts are automatically recalculated to provide the new total amount.*

Now the recipe is loaded!

The scale displays the first *ingredient number* to be loaded and then display the *ingredient amount* to be loaded. *These two values are alternately displayed until 5 percent of the ingredient is either loaded or unloaded.*

If using the *auto-advance feature*, and the weight is within the *"tolerance"* range, the alarms activate. This causes the internal *"delay timer"* to begin counting off the seconds required before automatically advancing onto the next ingredient.

Pressing the [INGR.#] or [PRINT] key also completes that ingredient and advances the scale to the next ingredient of the recipe.

If Delay Time is set to "MANUAL", the recipe does not advance until either the [INGR.#] or [PRINT] key is pressed twice. The first press completes the current ingredient and enters a "lock weight mode". This allows the scale system to be moved to a new location without affecting the weight amount of the next ingredient. The second press advances the scale recipe to the next ingredient.

See Pages 31 & 32 for more information.

After all ingredients have been loaded, the scale displays the message: "RECIPE COMPLETE TOTAL = XXXXXLB".

To_Review_a_Recipe:

Step 1) Press [RECIPE#]. The scale displays the first recipe loaded in memory. Press [RECIPE#] until the desired recipe number is displayed.

Step 2) Press [INGR.#]. This displays the ingredients of the recipe.

Step 3) Repeat step 2 to display all ingredients.

Step 4) Continue to press [RECIPE] until all recipes have been displayed or press [CLEAR] to exit the *"recipe review mode"*.

The indicator is easily attached to the Indicator Mounting Bracket by hooking the top over the plate and securing the bottom with two (2) screws (size $\#10-24 \times 5/8"$) and nuts.

Power Connection:

Warning!

Always disconnect the indicator power cord <u>before</u> ''jump starting'' or fast charging a battery. Disconnect <u>all</u> indicator leads before welding on equipment. Failure to do so can cause surges which will damage the scale.

The power cable should be connected directly to a vehicle battery or regulated power supply. The scale end of the power cable is attached to the **J901** connector located on the bottom panel of the scale.

Connect the **RED** wire from the power cable to +12 VDC and the **BLACK** wire to **GROUND**. The indicator is fused internally at 4 amps.

POWER CABLE CONNECTIONS:

WIRE COLOR	WIRE FUNCTION
RED	Battery(+12 VDC)
BLACK	GROUND
ORANGE	Remote Alarm Out +
BLUE	Remote Input

Remote Alarm Connection:

If a remote 12 VDC alarm is to be used, connect the +12 VDC side of the alarm to the power cable INDICATOR BOTTOM PANEL CABLE CONNECTIONS:

AUDIBLE ALARM

orange wire and the GROUND side of the alarm to the frame. The alarm output is fused for a maximum drain of 10 amps. The remote alarm connection may also be used for motor control purposes when used with a relay.

Remote Input Connection:

If the remote input is to be used, connect one side of the normally open momentary switch or relay contact to the power cable blue wire, and the other side to the frame or other GROUND connection. If your power cable does not contain a blue wire and you desire to use this feature, contact your dealer for a special cable. A process control box is available for motor control and remote *enter preset* capability.

Load Cell Connection:

The indicator operates with strain gage load cells. The system is normally supplied with a *"J-BOX"* cable going between the scale and the load cell junction box. Extension Kits are available from your dealer in various lengths.

To connect the load cells, attach the junction box cable to the **J902** connector on the bottom panel of the scale. Connect the load cell cables to the junction box as shown below.

Lightning Protection:

Additional protection is achieved with the proper installation of grounding rods. Please call (414) 563-5521 request J-Star Form F3050.

JUNCTION BOX LOAD CELL CABLE CONNECTIONS:

TERMINAL COLOR	DESCRIPTION
WHITE	SIGNAL +
GREEN	SIGNAL -
RED	EXCITATION +
BLACK	EXCITATION -
SHIELD	SHIELD
	TERMINAL COLOR WHITE GREEN RED BLACK SHIELD

NOTE: Follow color key on circuit board to insure proper connection of load cell wires. **MODEL 320** - Optional Features: Options are installed in the indicator if the corresponding keys are on the front panel or if additional connectors are on the bottom panel.

Remote_Display:

A Remote Display is available for viewing weights at convenient locations. The Remote Display includes a visual alarm light which can be used with the TR4 option listed below.

TR:_Radio_Control_Operation

The TR and TR4 options allow the operator to remotely control the scale from a distance up to 100 feet away.

The **TR** option allows the operator to perform "TARE and GROSS" or "Ingredient *Advance*" functions.

To_Print_Weight_Data:

Weight data can be sent to a printer by pressing the [PRINT] key.

An auto-print feature is implemented on the TR and TR4 options.

Sample output format shown below: 10JA92 12:01P * 123456 ID 123456LB GR "Clock" & "ID #" options also shown. To Print the Recipe Memory:

Step 1) Enter the program mode.

Step 2) Press [PRINT].

Print

All recipes currently residing in recipe memory will be printed.

To Print a Single Recipe:

The scale will display the first recipe in memory.

Step 2) Press [PRINT].

#

This prints the ingredients of this recipe. Press [RECIPE#] to advance onto the next recipe.

Step 3) Press [CLEAR] to exit, or continue to press [RECIPE] until all recipes have been displayed.

To_Enter_ID_Numbers-I.D.#:

Step 1) Use the numeric keypad to select the identification number.

Step 2) Press the [ID #] key to enter the identification number.

To_Display_ID_Numbers-I.D.#:

Step 1) Press the [ID #] key.

The identification number is also printed on every weight printout. Printing automatically clears the identification number so that a new value can be entered.

The identification number can also be cleared by pressing the [CLEAR] key followed by pressing the [ID #] key.

Black_Out:

The Black Out option is a preset enhancement that maintains the "*Preset amount left to go*" in *non-volatile*, permanent memory. This insures that the correct weight can be delivered *even* after a power outage.

For example, a system loaded with 2000Lbs was unloading a preset of 1000Lbs. After unloading the first 500Lbs, a power outage occurred. When the power returned and the scale was turned ON, the message "POWER OUTAGE - PRESS START ON CONTROL BOX TO FINISH PRESET - CLEAR TO CANCEL MO/DA/YR 12:00A" appeared.

Pressing START on the Control Box (or the [NET/GROSS] key on the scale) loads the preset amount remaining <u>before</u> the black out (500Lbs in this case).

Pressing the [CLEAR] key cancels the preset and the scale displays the GROSS weight.

The *Clock* option is required as part of the *Black Out* option. The *Clock* records the time, date, and preset remaining before the power outage (blackout).

Pulsed_Output:

The Pulsed Output option provides one (1) output line to indicate decreasing weight.

Pulsed Output pulls the connected signal line to ground through a 330 Ohm resistor for 150 milli-seconds every time the scale decreases one (1) display count.

1 Display Count = 1 Output Pulse The scale will not pull the line to ground more than twice (2 times) a second - **2 Hz**. For example, if the weight decreased from 8000 lbs. to 7500 lbs. using a display count of 10 lb counts.

8000 - 7500 = 500 (Lbs weight change) 500 / 10 (Display Count) = 50 (Pulses)

There would be 50 output pulses taking

about 25 seconds to output all 50 pulses.

In this example, 7500Lbs represents the "GROSS weight reference point". The scale resets the "GROSS weight reference point" if the weight increases 100 or more pounds for at least one (1) minute. The scale starts pulsing outputs as weight decreases from the new "GROSS weight reference point".

There are two (2) ways to "reset" or "abort" the internal pulse counter of the scale;

1 - ZERO/BALANCE the scale,

or 2 - Turn the scale "OFF" and then "ON" again and press "ZERO" when the scale shows the power outage message.

The *Clock* option is required as part of the *Pulsed Output* option. The *Clock* records the time, date, and "*GROSS weight reference point*" before the power outage (blackout).

When the scale power is returned and the scale is turned back *ON* after a power loss, the scale will display the message - *"POWER OUTAGE - PRESS NET/GROSS TO CONTINUE PULSED OUTPUT - ZERO TO RESET MO/DA/YR 12:00A"*. This provides the opportunity to start other equipment in the proper sequence.

The EZ R and EZ VIEW Remote Displays both feature a large 14 segment display capable of displaying the full alpha-numeric output of the EZ Series Indicators. The EZR provides a large 1 inch, 6 digit display; the EZ VIEW provides an even larger 1.7 inch, 6 digit display. Both have fiber-optic backlighting. They are not compatible with indicator models built prior to the EZ Series.

The EZ Remote Displays can also be equipped with a *Radio Control* feature, the optional *TR or TR4*. These options provide *remote control operation* of the EZ Indicator.

Turning_ON:

Step 1) Press the EZ Indicator [ON] key.

When the EZ Indicator is turned ON, the EZ Remote also turns ON showing the full (14 segment) alphanumeric display of the EZ Indicator. The EZ R Remote supports all of the annunciators used on the EZ Indicator. The EZ VIEW Remote supports three of the annunciators used on the EZ Indicator: "NET", "GROSS" and "CAL". The alarm lamp on the front panel of the EZ Remote turns ON whenever the EZ Indicator alarm lamp turns ON.

Turning_OFF:

Step 1) Press the EZ Indicator [OFF] key.

When the EZ Indicator is turned OFF, the EZ Remote also turns OFF.

Setup:

The EZ Indicator can be setup to work with either a Model 20R or an EZ R/EZ View Remote Display. When set incorrectly, the Remote displays nonsense even though it is connected to an EZ Indicator that is working properly.

The procedure for changing the "*REMOTE*" setup style is in *Section 3* of the "*Long Form Setup*"

Installation Requirements:

Remote_Display_Mounting:

The EZ Remote Display should be mounted in clear view. It is easily attached to the Mounting Bracket by hooking the top over the plate and securing the bottom with two (2) screws (size $\#10-24 \times 5/8"$) and nuts.

If equipped with a *Radio Control - TR/TR4* option, locate the Remote close to where the transmitter will be used. Keep the distance between the Remote Display and the handheld transmitter as short as possible and clear of obstructions. The *TR/TR4* option may be installed in the EZ Indicator instead of the Remote. To identify where it is located, disconnect the Remote from the Indicator. If the *TR/TR4* still works, it is installed in the Indicator. If the *TR/TR4* does not work, it is installed in the Remote.

If installation requires the cable to be removed from the Remote, remove the six (6) screws and pull out the front panel of the EZ Remote. If the front panel does not freely pull out, remove the EZ Remote from its mounting bracket, place the enclosure face down against a flat surface covered with a protective cloth, and tap the entire enclosure against the surface until the front panel pops out. One or two smart blows will generally pop the front panel loose.

With the front panel out of the enclosure, loosen the five (5) screws on the terminal block at the bottom edge of the circuit board. Pull each wire out of the terminal block. Loosen the plastic nut on the cable strain relief on the bottom panel of the enclosure and pull the cable out of the enclosure.

When re-installing the cable, be sure to place the wires in their correct locations. The decal shown (148200) is inside of the Remote Display to show wire positions.

Power_Connection:

Connect the cable of the Remote Display to the J903 REMOTE connector of the EZ Indicator. The Remote Display turns ON when the EZ Indicator is turned ON.

NOTE: Press the [ZERO] or [HELP] key for additional information during Setup and Calibration.

Entering & Exiting Setup Modes:

To Enter "Long Form" Setup/Calibration:

Step 1) Press and hold the [NET/GROSS] key, then press the [ON] key.

To Enter "Short Form" Setup:

Step 1) Press and hold the [ZERO] key, then press the [ON] key.

To Exit either Setup:

Step 1) Press and hold the [TARE] key, then press the [ON] key.

Entering Setup/Calibration Values:

Setup choices that are not numeric are selected by pressing the [NET/GROSS] key. It will show the various choices for that setup parameter.

Numeric entries are entered as follows:

For an EZ 150 - The [NET/GROSS] key increments the "flashing" digit and the [TARE] key selects which digit of the display is flashing.

For an EZ 210 or 320 - use the numerical preset keypad by first pressing [CLEAR] and then pressing the numeric keys 0 through 9. The method described above for the EZ 150 also works.

When the display shows the correct value, press the [ON] key to enter and store the value. If the display already shows the desired setting, press the [ON] key to advance to the next setup value.

The "Short Form" has only two values.

The "Short Form Values" are <u>NOT</u> displayed in "Long Form"! See Appendix A: for additional "Short Form" information.

To_enter_the_"Short_Form":

Step 1) Press and hold the [ZERO] key, then press the [ON] key.

Setup Number { SETUP }:

This value is made up of four different items: format-WGDRRR

W = Weigh Method. This value selects the weigh method or signal averaging scheme to be used by the scale system and the Display Unit:

Weigh Method Settings	Characteristic
1-LB	General
2-LB	Slow
3-LB	Fast
4-LB	Lock-On
5-KG	General
6-KG	Slow
7-KG	Fast
8-KG	Lock-On

See Appendix E for additional information.

G = **Gain.** This value selects the amplification to be used on the loadcell signal. This is application specific and should only be altered by trained technicians. <u>NOT</u> accessible in "Long Form".

D = **Display Count Index (0-9).** This is an index into the following table:

Note: Index 0 simply indicates a display count smaller than 0.2. These can be selected in the "Long Form".

Index	Display Count
0	0.01, 0.02, 0.05, & 0.1
1	0.2
2	0.5
3	1
4	2
5	5
6	10
7 1	20
8	50
9 1	00

RRR = **Capacity** * **1000.** This number represents capacity times one thousand.

An example of a **Setup Number** could be **"146040"**. This number represents:

- 1 General Weigh Method in LBS.
- 4 Gain setting of "4".
- 6 Display Count of "10".
- 040 Capacity of "40,000" (40 * 1000).

Calibration Number { CAL }:

This value represents the weight this scale would display with a loadcell input of .4mV/V.

An example of a **Calibration Number** could be **''032890''**.

NOTE: The system automatically returns to the normal weighing mode after Calibration Number.

The Setup/Calibration is split into three (3) groups. *Sections 2 & 3* are only accessible after sequencing through *Section 1*. The [ON] key must be pressed after each selection to allow the scale to update the value.

To EXIT the Setup / Calibration, press [ON] at the end of these three groups *or* press and hold the [TARE] and [ON] keys. The Setup/Calibration values that can be changed depends upon what options are installed. For example, the setup values Clock Time, Clock AM/PM, Clock Calendar, and Clock Marque will not be displayed if the "Clock Option" is not installed.

See Appendix B for additional information.

To_enter_the_"Long_Form":

Step 1) Press and hold the [NET/GROSS] key, then press the [ON] key.

Language { LANGAG }:

Select the *language* used to display the Help Messages. Example: English(*ENGLSH*), Dutch(*NEDERL*), French(*FRANCS*), German(*DEUTSH*), or Spanish(*ESPANL*).

Pre-Alarm Weight { P-ALM }:

This value represents a pre-alarm weight value (in LB's or KG's) which acts as a set point for activating the pre-alarm. This weight value can be entered by using the [NET/GROSS] and [TARE] keys or by using the numerical preset keypad. Selecting a pre-alarm weight of "0" disables this feature.

Clock Time { TIME }:

The "time of day" clock allows the seconds, minutes, and hour to be set. Pressing the [NET/GROSS] key increments the value of the flashing digit (seconds, minutes, or hours). Holding the [NET/GROSS] key down increments the digit at a faster rate (similar to setting a digital alarm clock). The [TARE] key selects which value is changed (seconds, minutes, or hours).

Clock AM/PM { AM/PM }:

NOTE: Only displayed if Time is changed. Selects either 'AM' or 'PM' for the internal clock.

Clock Calendar { DATE }:

The calendar allows the month, day, and year to be set. Pressing the [NET/GROSS] key will increment the value of the flashing digit (month, day, or year). Holding the [NET/GROSS] key down increments the digit at a faster rate (similar to setting a digital alarm clock). The [TARE] key selects which value is changed (month, day, or year).

Clock Marque { MARQUE }:

ON causes the scale to cycle between displaying the "time", "date", and "weight" when not weighing a load. Weight on scale must be close to "zero/balance" to see time and date.

Entry Method - Batcher { E MTHD }:

Select the entry method to be used when programming recipes.

Entry Method Selections

1 - Amount per Animal

2 - % per Load

3 - Amount per Load

See pages 24-27 for additional information.

Tolerance - Batcher { TOLER }:

Select the amount by percentage that an ingredient can be under/over-loaded and still automatically advance. Set to " OFF " to <u>always advance</u> after the ingredient amount has been reached.

<u>Tolerance Settings in Percentage</u> OFF, 0.5, 1, 2, 3, 4, 5, 7, or 10

See pages 31&32 for additional information.

Delay - Batcher { DELAY }:

Select the amount of seconds to wait before advancing the to the next ingredient of a recipe. Setting delay to "MANUAL" prevents auto advancing to the next ingredient. [PRINT] or [INGR. #] must be pressed to advance batcher to the next ingredient.

Delay Time Settings in Seconds

MANUAL, 1, 2, 3, 5, 7, 10, 20, 30, or 60

See pages 31&32 for additional information.

Motion { MOTION }:

Selecting ON causes the "MOTION" annunciator to flash if the weight is not stable. The following items are disabled until the weight is stable:

- Printer output.
- "Zero/Balance" function.
- "Tare" function.
- "Ingredient Auto-advance".

NOTE: Motion is temporarily "turned on" during all system weight calibrations to insure a stable measurement is obtained. It is "turned off" after calibration if "OFF" was selected in setup.

Display Update Rate { D RATE }:

This value selects the display update rate, 1, 2, 3, or 4 times per second (approx. 1, .5, .33, or .25 second intervals).

Weigh Method { W MTHD }:

Selects one of the several algorithms used to determine the displayed weights.

NOTE: Setting the Weigh Method in the "long form" **DOES NOT** affect the Display Unit (LB / KG).

Weigh Method

Setting Characteristic

1	General
2	Slow
3	Fast
4	Lock On

See Appendix E for additional information.

Zero Tracking { ZTRACK }:

ON will cause the scale to adjust for small weight variances. This allows the scale to compensate for such things as mud or snow accumulation on a platform scale. The maximum instantaneous weight zero tracking can remove is approximately

0.05% of the scales Capacity Limit value or

Max. Weight = .0005 * Capacity Limit

NOTE: Zero Tracking is temporarily turned OFF during all system weight calibrations

to insure a proper "ZERO/BALANCE" is obtained. It is "turned on" after calibration if "ON" was selected in setup.

The display will show the message: "PRESS NET/GROSS FOR CALIBRATION - TARE FOR SETUP - ON TO EXIT"

Press [NET/GROSS] to enter Section 2. Press [TARE] to enter Section 3. Press [ON] to exit.

Display Units { LB-KG }:

Select the scale to display in pounds (LB) or kilograms (KG).

Capacity Limit { CAP }:

This value is used to prevent over-loading of the scale system. The value entered for the scale capacity is usually equal to 105% of the load cell rated capacity or 105% of the total scale capacity, whichever is less.

Display Count Increment { COUNT }:

Use the [NET/GROSS] key to sequence through the available display count increments: .01, .02, .05, .1, .2, .5, 1, 2, 5, 10, 20, 50, and 100.

Zero { ZERO }:

The scale can be zeroed at this time by pressing the [NET/GROSS] key and within three seconds, press the [ZERO] key. If the scale does not require a new zero value,

Press the [ON] button to continue.

Full Scale Calibration { ADD WT }:

After the system has been properly zeroed, a known weight value should be placed on the scale platform (ex. 5000LB test weight). Pressing [NET/GROSS] will cause the scale to display the message " CAL" if the calibration weight exceeds 5% of the scale capacity, otherwise the system will not accept the calibration value and will show the message "ADD WT". More weight should then be added to the scale to exceed the 5% capacity weight. Once enough weight has been added, pressing [NET/GROSS] will cause the scale to display the message "CAL". Then the weight estimated to be on the scale at that time is displayed. This weight is estimated by using the "old" calibration value. The correct weight value can then be entered on the display by one of two methods:

For an EZ 150 - The [NET/GROSS] key will increment the "flashing" digit and the [TARE] key will select which digit of the display is flashing.

For an EZ 210 or 320 - use the numerical preset keypad by first pressing [CLEAR] and then pressing the numeric keys 0 through 9. The method described above for the EZ 150 will also work.

When the display reads the correct weight, pressing the [ON] key will automatically determine and store the full scale calibration value. The message "GOOD " is displayed for a successful calibration. The scale does not accept the weight entered if the weight is not stable (motion is detected) and displays the error message "MOTION".

If the calibration weight drops below the 5% of the scale capacity, an "*up arrow*" (^) will be displayed in the far left digit. When enough weight has been added to the scale system, the "*up arrow*" (^) will disappear. If the value entered by the operator does not exceed the 5% of capacity requirement, the scale will scroll the error message "*VALUE MUST BE MORE THAN XXXXX*". The scale value shown, (XXXXXX), will be the 5% capacity value needed for calibration.

If the scale's capacity is set too high for the internal gain setting, the scale displays the error message "CHGCAP" and then automatically enter the **Capacity Limit** {CAP} setup area to allow the capacity to be lowered.

The system automatically returns to the normal weighing mode after Full Scale Calibration.

To enter the last area of the "long form" reenter *Section 1:*, repeatedly press [ON] to advance through the setup values, but stop <u>after</u> Zero Tracking. Now press [TARE].

Remote Input { RM INP }:

When set to 'PRESET' the Remote Input on the power cord (and the input from the 20R/TR option) will re-enter the last preset value entered. When set to 'TARE' the Remote Input performs the "TARE" function and zero the display.

The EZ 320 Batcher replaces 'TARE' with 'INGRED'. This causes the Remote Input to advance ingredients if a recipe is loaded. It performs a *tare* if no recipes are loaded.

Alarm Output { AL OUT }:

When set to 'TR', causes the alarm capabilities of the "preset alarm" to be controlled by the TR/TR4 keys. The Front Panel Alarm Light and the relay output is ON(+12V) when a TR/TR4 key command has been accepted by the scale. 'PRESET', causes the alarm capabilities to be controlled by the "preset alarm".

Remote Style { REMOTE }:

'20R' causes the data being sent to the remote display to be in the 20R format. 'EZR' uses the EZR remote display format.

Alarm Buzzer { BUZZER }:

ON allows the pre-alarm, preset, and TR/TR4 keys to create audible alarm sounds. OFF prevents all audible alarm sounds except for Front Panel key closures.

TR Inventory Hold { TR HLD }:

ON causes the scale to enter the GROSS mode when the TR is pressed "twice" within a three(3) second time period.

When pressed "once", the TR will "ZERO" the display and enter the "NET" mode.

If OFF, the "GROSS" weight is momentarily displayed when the TR is pressed twice within 3 seconds and then return to the "NET" mode.

Raw A/D Display Counts { DSP AD }:

Not available on all units. ON causes the display to show "raw" or "unscaled" Analog-to-Digital values. <u>Used</u> <u>only by service personnel.</u> When OFF, scale displays "scaled" display counts. **Should be "OFF" for normal operation.**

Clear Memory { CLR M }:

When set to 'TR NG', TR4 button #2 toggles between the NET and GROSS modes. When set to 'TR CM', TR4 button #2 clears the Weigh Memory.

Tare Auto-Print { TAREAP }:

ON causes the scale to auto-print the displayed weight everytime the [TARE] key is pressed.

One Line Print { 1L PRT }:

ON causes the scale to print all output information on one (1) line.

Print Delay { PRTDLY }:

Selection not available on all units (always ON in "PRG ID" versions "EZ B5", "EZ B6", and newer). ON causes the scale to insert time delays between print outputs. This feature is used with unbuffered or slow printers.

Lock-On { LOCKON }:

Select a value 1 through 9 to adjust the *"Lock On"* weigh method. By selecting a low value such as 1 or 2, the system becomes more sensitive to animal movement. Selecting a high number such as 8 or 9 will allow the scale to *lock-on* faster. Use the lowest setting that still allows the system to consistantly *lock-on*.

Preload Tare { PRETAR }:

ON enables the "*Preload Tare*" feature which allows the tare weight of a container to be entered using the numeric keypad of an EZ 210 or an EZ 320.

Preset Auto Clear { PRECLR }:

ON enables the "*Preset Auto Clear*" feature. This automatically stores the "*preset amount remaining*" of an active preset into internal memory <u>if</u> the displayed weight does not change more than +/- 2 display counts for 45 minutes. The "*preset amount remaining*" can be reloaded by grounding the Remote Input (BLUE wire) on the Power Cable. This causes a "*re-enter preset*" function to occur (See - Remote Input).

The original preset amount will be entered on the next *"re-enter preset"*, once the current preset has been satisfied by loading or unloading the scale.

Estimated Weight { EST WT }:

A new GROSS weight can be entered at this time by using either the [NET/GROSS] & [TARE] keys or the numeric keypad. This feature changes the "zero/balance" of the scale to display the *"estimated gross weight"* entered.

The display shows the message: "PRESS ON TO EXIT". Press [ON] to exit.

Exiting Setup/Calibration Mode:

Setup/Calibration mode can be exited by three methods:

1 - Press and hold the [TARE] key, then press the [ON] key at anytime.

2 - Pressing the [ON] key at the end of Sections 1 and 3.

3 - Automatically after the last set up value has been entered in Section 2.

turn off the unit.

4 - Press the [OFF] key to

Off

45

Initiating Self Test:

Wait until normal operation has begun and press the [ON] key.

During self test operation, the 'TEST' annunciator will flash.

Test Sequence:

Start of Test Sequence: Display *"TEST"* message.

Display Set Up Values:

Short Form Setup Value first, then the Short Form Calibration Number.

Display Test:

Cycle through all display segments to identify any faulty areas.

Display Program ID: Display the program revision level.

System Test:

Scale displays "RUNNING SELF TEST -PLEASE WAIT" while performing internal system testing.

Self Test System Errors:

If system errors are discovered during internal diagnostics, the operator will see an error message (example: "- ERROR 1 -PRESS NET/GROSS TO CONTINUE" followed by "*** INDICATOR NEEDS SERVICE *** PRESS NET/GROSS TO CONTINUE").

Halting the Test:

Pressing the [ON] key during the test halts the sequence. Pressing it again restarts the test.

Terminating the Test:

The self test terminates and continues normal operation if no errors are detected or if keys other than [ON] are pressed.

NOTES:

1:If the Scoreboard option is installed, the scale sends the message "*TEST* " on the scoreboard data line.

2: Sending a command using the Computer Interface causes the system to skip the error messages and attempt normal system operation.

3: The test cannot be terminated while the *"RUNNING SELF TEST - PLEASE WAIT"* message is displayed.

Capacity Limit:

The display shows the message "OVRCAP" if the weight on the scale system exceeds the over capacity limit. The over capacity value is the setup parameter "capacity". This value is entered in "SETUP" to prevent over-loading of the scale system.

Over Range:

The display shows the message "+*RANGE*" if the weight on the scale system exceeds the "plus range" or maximum weight measurable by the scale system. The over range value is always the systems maximum A/D counts multiplied by the scaling factor. The actual weight at which over-range occurs depends on the calibration, zero, and display count size.

Under Range:

The display shows the message "-RANGE" if the weight on the scale system is less than the "minus range" or minimum weight measurable by the scale system. The under range value is always the systems minimum A/D counts multiplied by the scaling factor. The actual weight at which under-range occurs will depend on the calibration, zero, and display count size.

NOTE: Annunciators for 'NET', 'GROSS', and 'LOAD' will "flash" when "ON".

'MOTION': The arrow pointing to "MOTION" on the front panel flashes when the indicator is unstable or in "MOTION".

'PROGRAM': The arrow pointing to "PROGRAM" on the front panel flashes when recipe's are being programmed.

'TEST': Flashes when the indicator is performing its' self-test. 'TEST' will be on continuously if the test has been halted.

'CAL': Flashes when the indicator is in the "Setup/Calibration" mode.

'PRESET': The triangle pointing to "PRESET" on the front panel overlay turns on when a preset is loaded. The inner arrow turns on when the preset is active.

'PRINT': The arrow pointing to the [PRINT] key on the front panel turns on when the unit is sending data to the printer.

'ID #': The arrow pointing to the [ID **#**] key on the front panel turns on when an identification number is loaded.

'M+': The arrow pointing to the [M+] key on the front panel turns on when a value has been saved in the Weigh Memory.

'RECIPE#': The arrow pointing to the [RECIPE#] key on the front panel turns on when a recipe is being loaded.

'GROSS': The arrow pointing to "GROSS" on the front panel flashes when the unit is in the *gross mode*.

'KG': Turns on when output units are in kilograms.

'LB': Turns on when output units are in pounds.

'LOAD': The arrow pointing to "LOAD" on the front panel flashes when the indicator is loading or unloading using the preset capabilities.

'NET': The arrow pointing to "NET" on the front panel flashes when the indicator is in the *net mode*.

- Access; **Zero** and hold then

On

First LCD Screen "Setup":

1000

Weigh Method					
1	2	3	4 = lbs		
5	6	7	8 = kg.		
General	Slow	Fast	Lock-on		

Gain (1 thru 9)				
60hz	Max Signal	50hz	Max Signal	
1	2.0	6	1.9	
2 3	1.5 1.14	8	1.3 .97	
4 5	.84 .47	9	.66	

Display Counts (0-9)										
	0	1	2	3	4	5	6	7	8	9
.01 .02 .05	.1	.2	.5	1	2	5	10	20	50	100
↑ Select in long form only										

Δ

Δ

Capacity X

On Press for second LCD Screen "CAL":

CALIBRATION NUMBER (Calibration weight at 0.4 mv/v)

	- Access: Groa	and hold the	en On until beeps.
	Parameters list	follows. Abo	rt with house and On
1.	P-ALM		Pre-Alarm weight in actual display counts.
2.	TIME	Time of day	Hrs : Min : Sec and a.m. or p.m.
3.	DATE Calenda	r Mont	h:Day:Year.
4.	MARQUE	ON/OFF	When ON, display alternates between Time/Date/Weight.
5.	E MTHD	1/2/3	Entry Method; 1-amount/animal, 2-percent/load, or 3-amount/load.
6.	TOLER	Tolerance	Ingredient Percentage; OFF, .5, 1, 2, 3, 4, 5, 7, 10.
7.	DELAY	Delay	Seconds Delay; MANUAL, 1, 2, 3, 5, 7, 10, 20, 30, or 60.
8.	MOTION	ON/OFF	When ON, instability inhibits scale operation.
9.	D RATE	1/2/3/4	Display update rate; times per second.
10.	W MTHD	1/2/3/4	Weigh method; General/Slow/Fast/Lock-On.
11.	Z TRACK	ON/OFF	Zero tracking feature.
			-

to exit, On

Net Gross to calibrate, or

to set up Tare

- CALIBRATE -

12.	LB/KG	Pounds/Kilograms	Unit of Measure.	Calibration is converted	automatically.
-----	-------	------------------	------------------	--------------------------	----------------

- 13. CAP
- Maximum display weight. Display Count Size; 0.01, .02, .05, .1, .2, .5, 1, 2, 5, 10, 20, 50, 100. 14. COUNT
- Balance the scale now. 15. ZERO
- Add Calibration weight. 16. ADD WT
- Enter true weight now. 17. CAL

- SET UP -

18.	RM INP	Remote Input TARE/PRESET	Function of fourth wire in power cord. (Model EZ210).
		- or -	
		INGRED/PRESE	ET (Model EZ320).
19.	AL OUT	Alarm Output	Function of alarm line for EZ 210's & EZ 320's.
		TR-TR4/PRESE	Γ (If TARE or INGRED is selected in Step 15).
		- or -	
		TR4/PRESET	(If PRESET is selected in Step 15).
20.	REMOTE	EZR/20R	Remote model (select EZR for use with EZ VIEW).
21.	BUZZER	ON/OFF	Local buzzer alarm.
22.	TR HLD	ON/OFF	Inventory (Gross) hold with second key.
23.	DSP AD	ON/OFF	Service feature: displays internal counts (not in all versions).
24.	CLR M	TRCM / TRNG	Selects function of fourth key on TR4.
25.	TAREAP	ON/OFF	Tare with auto print feature.
26.	1L PRT	ON/OFF	Prints on one line instead of two lines(requires 35 column printer).
27.	PRT DLY	ON/OFF	Inserts delays for non-buffered printers(always ON in newer
versio	ns).		
28.	EST WT		Estimated gross weight.

Signal Levels:

The Printer, Computer, and Scoreboard are capable of communicating using the EIA Registered Standard #232 (RS-232). The signal levels move between +8 and -8 Volts.

The Scoreboard also has another communication port that drives 20 milli-Amp devices.

Communication Parameters:

Data is transmitted and received in the asynchronous ASCII format. This communication format is compatible with the Model 15XT and most other printers, computers, and terminals.

Port Configuration:

1200 BAUD1 Start Bit7 Data Bits1 EVEN Parity Bit1 Stop Bit

"Handshake lines" are <u>not</u> used and XON/XOFF is <u>not</u> supported.

These parameters are <u>not</u> adjustable in the scale. Equipment interfacing to the scale must match this configuration.

Port Wire Connections:

All serial communications use the J904 connector on the bottom panel of the scale.

Device	Function J	904 Pin
To Printer	RS-232 out	pin 2
	Printer ground	pin 6
From Compute	r RS-232 in	pin 3
	Computer grou	ind pin 5
To Scoreboard	RS-232 out	pin 4
	Scoreboard gro	ound pin 7

also on the J904 connector:

Device	Function	J904	Pin
Scoreboard	1 20mA Curren	t Loop(+)	pin 1
Scoreboard	1 20mA Curren	t Loop(-)	pin 8

See Appendix D for additional information.

Computer Command Set:

The Computer Interface controls the scale's operation by a remote RS-232 computer. Most commands acknowledge completion of the command by outputting the appropriate data stream.

Single Letter commands are always in capitols (UPPER CASE).

The following *Single Letter* commands are supported:

- 'A' Advance recipe to next ingredient.
- 'B' Balance indicator, enter GROSS mode.
- 'C' Perform CM (Clear Memory).
- 'D' Perform "recheck weight" for "Lock-On" weigh method.
- 'E' Display & re-enter previous preset value. *No print output*.
- 'G' Enter GRÔSS mode.
- 'I' Display the "ID NO" number.
- 'L' Enter L/UL mode if applicable.
- 'M'- Perform M+ (Memory Plus).
- 'N' Enter NET mode. TARE if necessary.
- 'P' Print weight data. This command will also advance to the next ingredient if the scale is processing a recipe.
- 'Q'- Print *last Recipe Number loaded*. Ingredient number will also be printed if recipe is currently active.
- 'R'- Perform RM (Recall Memory).
- 'T' Perform TARE and enter NET mode.
- 'Y'- Print Setup Number. *Also* temporarily outputs the Setup Number to the Scoreboard.
- 'Z'- Print Calibration Number. *Also* temporarily outputs the Calibration Number to the Scoreboard.

Format Example - B

B - (ASCII Dec. 66) Zero/Balance command. *Numeric Entry* commands are *not* in capitols (lower case). They are sent with the numbers first (one to six numbers with values 0-9) followed by a lower case letter.

The following *Numeric Entry* commands are supported:

- 'f' Clears "Blackout", "Pulsed Output", and "Recipe" errors at scale startup.
- 'g' Load a preset (0-999999), enter GROSS mode (0 clears preset).
- 'i' Load the "ID NO" number 0-999999.
- 'l' Load a preset (0-999999), enter L/UL mode (0 clears preset).
- 'n' Load a preset (0-999999), enter NET mode (0 clears preset).
- 'r' Loads a Recipe (0-99).
- 't' Preload a TARE value 0-999999.
- 'v' Amount for recipe (0-999999). Should precede the recipe command 'r'.
- 'y' Enter Short Form Setup Value (100000 999999).
- 'z' Load Short Form Calibration Number (1 - 99999).
- **Format Example** 2000g
- 2000 PRESET weight.
- g (ASCII Dec. 103) Gross Preset command.

Scoreboard Data Format:

Data is sent from the scale to the scoreboard 4 to 8 times each second. The weight data is sent in the following format:

<stx>ABBBCD<cr>

Where:

- <stx> is the ASCII control code "START OF TEXT"(dec. 2).
- <cr> is the ASCII control code "Carriage Return" (dec. 13).
- A is either a minus sign, SPACE, number, or a dollar(\$). *The dollar(\$) appears when the indicator is setup for the* <u>"Lock</u> <u>On" weigh method</u> and has "locked onto" a weight value.

B is a number or a SPACE.

- C is a number, SPACE, or a '-' minus sign indicating a TR command is active.
- D is a number or a '-' minus sign indicating that motion is active.

If the Clock option is installed with Marquee **ON**, date and time data is sent in the following format:

	<stx>mo-dy_<cr> for Date <stx>hh mmA<cr> for Time</cr></stx></cr></stx>						
Wher	e:						
<stx></stx>	is the ASCII control code "START OF TEXT"(dec. 2).						
<cr></cr>	<cr> is the ASCII control code "Carriage Return" (dec. 13).</cr>						
mo	is the Month.						
dy	is the Day.						
hh	is the Hour.						
mm	is the Minute.						
A	is A for AM, P for PM.						
_	represents a SPACE.						

Print Data Format - Two Line:

Data is sent from the scale to the printer whenever the

- [PRINT] key is pressed.
- TR4 or TR options are used.
- Tare auto-print (TAREAP) is ON.

Date and Time make up the first line and will only be present if the *Clock Option* is installed.

The data is sent in the following format:

_____dymoyr__hh:mmA<cr><lf> xxxxxxID__yxxxxLB_GR<cr><lf>

Where:

- <cr> is the ASCII control code "Carriage Return" (dec. 13).
- is the ASCII control code "Line Feed" (dec. 10).

represents a SPACE.

- dymoyr is date (Day,Month,& Year).
- hh:mm is Time (hours:minutes). А is either A(AM), or P(PM). is a number(0-9), or a Х SPACE. ID labels the Identification Number (I.D.#). is a number(0-9), SPACE, or у a minus sign '-'. is either Pounds(LB), or LB Kilograms(KG). GR labels the weight amount. GR - Gross NE - Net TA - Tare M+ - Memory Plus RM - Recall Memory CM - Clear Memory TP - Tare Point Entered

Print Data Format - One Line:

Data is sent from the scale to the printer whenever the

- [PRINT] key is pressed.
- TR4 or TR options are used.
- Tare auto-print (TAREAP) is ON.

Date and Time make up the last part of the line and are only present if the *Clock Option* is installed.

The data is sent in the following format:

xxxxxxID_yxxxxxLB_GR_dymoyr_hh:mmA<cr><lf>

Where:

- <cr> is the ASCII control code "Carriage Return" (dec. 13).
- is the ASCII control code "Line Feed" (dec. 10).

_ represents a SPACE.

- dymoyr is date (Day, Month, & Year). hh:mm is Time (hours:minutes). is either A(AM), or P(PM). А is a number(0-9) or a SPACE. Х ID labels the Identification Number (I.D.#). is a number(0-9), SPACE, or a у minus sign '-'. is either Pounds(LB), or LB Kilograms(KG). GR labels the weight amount. **GR** - Gross NE - Net TA - Tare M+ - Memory Plus
 - RM Recall Memory CM - Clear Memory
 - TP Tare Point Entered

Recipe Print Data Format:

Data is sent from the scale to the printer whenever the

- [PRINT] or [INGR#] key is pressed while loading a recipe.
- Single recipe is being printed.
- All recipes are being printed.

The data is sent in the following format:

I ING#xx *ING#xx ING#xx *ING#xx	RECIPE#_xx <cr><lf> ymoyrhh:mmA<cr><lf> x_yxxxxxLB_NE<cr><lf> x_yxxxxxLB_NE<cr><lf> x_yxxxxxLB_NE<cr><lf> x_yxxxxxLB_NE<cr><lf> x_yxxxxxLB_NE<cr><lf></lf></cr></lf></cr></lf></cr></lf></cr></lf></cr></lf></cr></lf></cr>
Where:	
-	represents a SPACE.
RECIPE#	labels the Recipe Number (RECIPE#).
Х	is a number(0-9) or a SPACE.
У	is a number(0-9), SPACE, or a minus sign '-'.
<cr> is the A Return</cr>	ASCII control code "Carriage " (dec. 13).
<lf> is the A Feed" (</lf>	ASCII control code "Line (dec. 10).
dymoyr	is date (Day,Month,& Year).
hh:mm	is Time (hours:minutes).
А	is either A(AM), or P(PM).
*	indicates the recipe was advanced <i>manually</i> when in the <i>auto-advance</i> mode.
ING#	labels the Ingredient Number (INGR.#).
LB	is either Pounds(LB), or Kilograms(KG).
NE	labels the weight amount.

TOTAL = Total of all listed ingredients.

Print Samples:

Shown below are additional print samples from the J-Star "EZ" family of scale indicators.

General Information:

The weight and Identification Numbers can have leading spaces. The weight information can have a decimal point (100910 or 10091.0). The ASCII Carriage Return (Dec. 13) is represented as <. The ASCII Line Feed (Dec. 10) is represented as ^.

In order to identify the line location of the characters, a simple column position identifier is shown directly above the PRINT DATA:

```
1 2 3 4
1234567890123456789012345678901234567890
```

So for example - Print Data with the Identification Number Option;

Shows that the:

ID# (123456ID) starts at column 1 of line 1.

WEIGHT ($109700LB \rightarrow 109,700$ pounds) starts at column 10 of line 1.

GR Scale was in the GROSS mode, starts at column 19 of line 1.

<^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).

<^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).</p>

The same Print Data with Identification Number & Clock Options;

	1	2	3	4				
123456789	90123456789	90123456789	012345678	90				
21.	JA91 11:22#	A<^		<-	PRINT	DATA	LINE	1
123456ID	109700LB 0	₩<^<^		<-	PRINT	DATA	LINE	2

Shows that the:

DATE $(21JA91 \rightarrow January 21, 1991)$ starts at column 7 of line 1.

TIME $(11:22A \rightarrow 11 \text{ hours}, 22 \text{ minutes AM})$ starts at column 14 of line 1.

<^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).

ID# (123456ID) starts at column 1 of line 2.

WEIGHT ($109700LB \rightarrow 109,700$ pounds) starts at column 10 of line 2.

GR Scale was in the GROSS mode, starts at column 19 of line 2.

<^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).

<^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).</p>

The same Print Data with Identification Number & Clock Options, BUT with the One Line Print (1L PRT) feature enabled;

1 2 3 4 123456789012345678901234567890 1234561D 109700LB GR 21JA91 11:22A<^ <- PRINT DATA LINE 1

Shows that the:

ID# (123456ID) starts at column 1 of line 1. WEIGHT (109700LB -> 109,700 pounds) starts at column 10 of line 1. GR Scale was in the GROSS mode, starts at column 19 of line 1. DATE (21JA91 -> January 21, 1991) starts at column 22 of line 1. TIME (11:22A -> 11 hours, 22 minutes AM) starts at column 29 of line 1. <^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).

The Print Data for an EZ320 with Identification Number & Clock Options while loading a recipe;

		1	2	3	4
1	23456789	9012345678	39012	345678901	234567890
	RI	ECIPE# 16	<^		
	21.	JA91 11:22	2A<^		
	ING#01	90LB	NE<^		
*	ING#02	0LB	NE<^		
	ING#03	490LB	NE<^		
	ING#04	1000LB	NE<^		
	TOTAL =	1580LB	<^<^		

Shows that the:

RECIPE# (Recipe Number 16) starts at column 8 of line 1. <^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).

DATE (21JA91 -> January 21, 1991) starts at column 7 of line 1. TIME (11:22A -> 11 hours, 22 minutes AM) starts at column 14 of line 1. <^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).

ING# (Ingredient # 01) starts at column 3 of line 3.

WEIGHT (90LB -> 90 pounds) starts at column 10 of line 3.

NE Scale was in the NET mode, starts at column 19 of line 3.

<^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).

* ING# (* - Manual Advance Ingredient # 02) starts at column 1 of line 4. The scale is loading a recipe using the "auto-advance" feature. The '*' indicates that the operator pressed either the [INGR.#] or [PRINT] key to force the scale to advance to the next ingredient before the meeting the conditions of the auto-advance (ex. Tolerance, Delay, Motion).

WEIGHT ($0LB \rightarrow 0$ pounds) starts at column 10 of line 4.

NE Scale was in the NET mode, starts at column 19 of line 4.

<^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).

ING# (Ingredient # 03) starts at column 3 of line 5. WEIGHT (490LB -> 490 pounds) starts at column 10 of line 5. NE Scale was in the NET mode, starts at column 19 of line 5.

<^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).

ING#(Ingredient # 04) starts at column 3 of line 6.WEIGHT(1000LB -> 1000 pounds) starts at column 10 of line 6.NEScale was in the NET mode, starts at column 19 of line 6.<^</td>Carriage Return (Dec. 13) & Line Feed (Dec. 10).

TOTAL = Total amount starts at column 2 of line 7. WEIGHT (1580LB -> 1580 pounds) starts at column 10 of line 7. <^ Carriage Return (Dec. 13) & Line Feed (Dec. 10). <^ Carriage Return (Dec. 13) & Line Feed (Dec. 10).

Computer Interface Print Samples:

Most commands acknowledge completion of the command by outputting the appropriate data stream.

Single Letter commands are always in capitols (UPPER CASE).

Numeric Entry commands are *not* in capitols (lower case). They are sent with the numbers first (one to six numbers with values 0-9) followed by a lower case letter.

Single Line print feature is shown below - this can be selected in the "Long Form Setup".

Command Sent	<u>Printer C</u>	<u> Dutput Data</u>	Str	eam		
		1	2		3	4
	12345678	9012345678	8901	1234567	890123456	7890
Y	123456ID	145052S#	S#	10JL93	3 7:08P	
Z	123456ID	40000LB	C#	10JL93	3 7:08P	
N	123456ID	260LB	NE	10JL93	3 7:09P	
В	123456ID	0LB	ZR	10JL93	3 7:09P	
Т	123456ID	600LB	TA	10JL93	3 7:09P	
G	123456ID	600LB	GR	10JL93	8 7:10P	
Μ	123456ID	605LB	M+	10JL93	3 7:10P	
М	123456ID	605LB	M+	10JL93	3 7:10P	
R	123456ID	1210LB	RM	10JL93	3 7:10P	
С	123456ID	0LB	СМ	10JL93	3 7:10P	
<u>Command Sent</u>	<u>Printer C</u>	output Data	Str	eam		
		1	2		3	4
	12345678	9012345678	8901	1234567	890123456	7890
2500v1 m	וס					
2500011	10	TT.93 7:0'	7Þ			
N	TNG#01	01.B	NE.	< -	NET weight	t loaded for ING#01
G	ING#01	3890LB	GR	< -	GROSS weight	aht on scale
G T,	ING#01	1000LB	LII	<-	NET weight	t vet to be loaded for
TNG#01	11101101	1000110	10		indi weigin	
0	ING#01	1R#	R#	<-	Recipe and	d Ingredient number.
P	* ING#01	0LB	NE	<-	Print Ing	redient and advance
Recipe.						
A	* ING#02	0LB	NE	<-	Advance Re	ecipe and print
Ingredient.						1 1
P	* ING#03	0LB	NE	<-	Print Ing	redient and advance
Recipe.					2	
-	TOTAL =	0LB		<-	Total is a	automatically printed
upon						
					completion	n of Recipe.

KEY OTY PART NUMBER DRWG. No. DESCRIPTION 1 1 1 141603 A141603 TUBING, HEAT SHRINK 3/4" 2 1 141607 A141607 CONN. HOOD, SERIES 1 3 1 141641 B141641 CONN. HOOD, SERIES 1 4 1 141650 B141650 CONN. HOOD, D-SUB 5 Action 141820 A141650 CONN. HOOD, D-SUB 6 3 143970 A141642 TUBING, HAET SHRINK 3/4" 7 1 840550 A141642 TUBING, HAET SHRINK 3/4" 8 3 840550 A141642 SINNK 3/4" 9 1 840552 CONN. PIN/F SHRINK 3/4" 9 2 144055 A840550 TUBING, HAET SHRINK 3/4" 10 2 144052 A840550 TUBING, HAET SHRINK 3/4" 7 1 840552 CONN. BODY/M B-PIN SERIES 2 10 9 2 144055 A145516 MRE, BARE, 24 GA, SOLID	As Required As Required	ADED RET 6. OHNOED PART DESCRIPTION DEAMING TITLE J-STAR NDUGRIER, INC. DRAWING TITLE ADED RET 6. OHNOED PART DESCRIPTION BOT MARCENEL AND MERLE AND AND MERLE AND MERLE AND AND MERLE AND AND AND MERLE AND AND AND AND MERLE AND AND AND MERLE AND AND MERLE AND
ASSEMBLY INSTRUCTIONS ASSEMBLY INSTRUCTIONS 1. CUT OUTER JACKET TO LENGTH SHOWN. 2. CUT OUTER JACKET TO LENGTH SHOWN. 3. STRIP WIRE END SITUPINS, KEY 8, ON WIRE ENDS. 5. INSERT PINS INTO KEY 9, USING TABLE 1. 6. PLACE HEAT SHRINK TUBING, KEY 6, OVER EACH WIRE AND SOLDER WIRE TO KEY 3, USING TABLE 2. 7. PLACE HEAT SHRINK TUBING, KEY 6, OVER EACH WIRE AND SOLDER WIRE TO KEY 3, USING TABLE 2. 8. CUT JUMPERS FROM BARE WIRE, KEY 10: INSTALL AND SOLDER IN PLACE USING TABLE 2. REMOVE EXCESS FLUX FROM KEY 3. 9. SHRINK TUBING OVER SOLDER JOINTS & CONNECTOR, KEY 2, 10. INSTALL PROTECTIVE CONNECTOR HOOD, KEY 4.		$ \bigoplus_{\substack{25 \\ c} \circ $

KEY GTV PART NUMBER DRW. NO. DESCRIPTION 1 1 1 141603 A141607 TUBING, HEAT SHRINK 3/4" 2 1 141607 A141607 CONN. HOOD, SERIES 1 2 1 141607 A141607 CONN. HOOD, SERIES 1 3 1 141820 A141820 CABLE, 4-COND W/SHIELD 4 1 840500 A840502 TUBING, HEAT SHRINK 3/8" 5 3 840552 A840552 CONN. PIN/F SERIES 2 6 1 840553 CONN. BODY/M B-PIN SERIES 2	3-REF.	Image: Second condition of the
ASSEMBLY INSTRUCTIONS 1. CUT OUTER JACKET TO LENGTH SHOWN. 2. CLIP UNUSED RED WIRE & SHIELD WIRE. 3. STRIP WIRE ENDS TO LENGTH SHOWN. 4. INSERT PINS INTO KEY 6, USING TABLE 1. 5. PLACE HEAT SHRINK TUBING KEY 1 & KEY 4, OVER CABLE. SHRINK TUBING OVER CONNECTOR HOOD, KEY 2.	VIEW A-L VIEW A-L VIEW A-L VIEW A-L Table 1 VIEW A-L VIEW A-L VIEW A-L VIEW A	E 1492 ADED REY 3, CH4NGED PAK D 10013 DLEFED REY 3, 1141820 D 0003 KT 3, 1141820 C 9486 CH4NGED DTV, KEY 6, FROM A 86-63 RELEASED REV NUMBER DESCRIPTION OF

PART NUMBER DRWC. NO. DESCRIPTION 141603 A141603 TUBINC, HEAT SHRINK 3/4" 2.5" 141607 A141607 CONN. HOOD, SERIES 1 141641 B141641 CONN. HOOD, SERIES 1 141650 B141650 CONN. HOOD, D-SUB 141650 B141650 CONN. HOOD, D-SUB 141650 B141650 CONN. HOOD, D-SUB 141811 A141811 TUBING, HEAT SHRINK 3/8" 840500 A840500 TUBING, HEAT SHRINK 3/8" 840553 B840553 CONN. BODY/M 8-PIN SERIES 2 840553 B840553 CONN. BODY/M 8-PIN SERIES 2	TABLE 2 WIRE PIN NO. FUNCTION BLACK 7 SIGNAL GROUND GREEN NOT USED TA WHITE 3 PRINTER DATA SHIELD NOT USED	More More MATERIAL # 0002 # 0002 More MATERIAL # 010 # 010 # 0112/se # 10 # 1 # 010 # 10 # 10 # 1 # 10 # 10 # 10 # 1 # 10 # 10 # 10 Scale # 11 # 10 # 10 Scale # 11 # 10 # 10 Scale # 11 # 10 # 10
EMBLY INSTRUCTIONS KEY PA FR JACKET TO LENGTH SHOWN. ER JACKET TO LENGTH SHOWN. 2 1 14 USED RED WIRE & SHIELD WIRE. Instructions 3 1 14 USED RED WIRE & SHIELD WIRE. Instructions 3 1 14 USED RED WIRE & SHIELD WIRE. Instructions 5 1 14 INS, KEY 8, ON WIRE ENDS. Instructions 6 3 14 INS, KEY 8, ON WIRE ENDS. PANE TO LENGTH SHOWN. 6 3 14 INS, KEY 8, ON WIRE ENDS. PANE TO LENGTH SHOWN. 6 3 14 PINS INTO KEY 9, USING TABLE 1. PART RINK TUBING, KEY 1 & KEY 7, OVER CABLE. 6 3 3 84 EAT SHRINK TUBING, KEY 1 & KEY 7, OVER CABLE. EAT SHRINK TUBING, KEY 6, OVER EACH WIRE 7 9 1 84 3 84 DER WIRE TO KEY 3, USING TABLE 2. TUBING OVER SOLDER JOINTS & CONNECTOR. 9 1 84 1 1 84 PROTECTIVE DATAPHONE HOOD, KEY 4. A A 1 1 84 1 84 1 84 1 84 1<	1 1 FUNCTION FUNCTION SIGNAL GROUND 0 SIGNAL GROUND 0 Manual Group 0 Manual Group <t< td=""><td>C 14932 CH-MREED GTV, KEY & FROM 3 TO 2 G0/30/781 3_602 C 14932 CH-MREED GTV, KEY & FROM 3 TO 2 G0/30/781 3_602 C 14932 CH-MREED GTV, KEY & FROM 3 TO 5 G0/30/781 ACLLE DAL B 6668 CH-MREED CH-MREED G1/30/791 3_602 HDLLE DAL A 6621 FELLEKEID G0/30/761 Q0/30/761 MACH. FINISH REV NUMBER DESCRIPTION OF CHANGE DATE CK'D DO NOT SCI</td></t<>	C 14932 CH-MREED GTV, KEY & FROM 3 TO 2 G0/30/781 3_602 C 14932 CH-MREED GTV, KEY & FROM 3 TO 2 G0/30/781 3_602 C 14932 CH-MREED GTV, KEY & FROM 3 TO 5 G0/30/781 ACLLE DAL B 6668 CH-MREED CH-MREED G1/30/791 3_602 HDLLE DAL A 6621 FELLEKEID G0/30/761 Q0/30/761 MACH. FINISH REV NUMBER DESCRIPTION OF CHANGE DATE CK'D DO NOT SCI
ASS 1. CUT OU 2. CLIP UN 3. STRIP W 4. CRIMP F 5. INSERT 6. PLACE F AND SO 8. SHRINK 9. INSTALL	Itable WIRE PIN NO. WHE PIN NO. BLACK 6 GREEN NOT USED WHIE 2 RED NOT USED SHIELD NOT USED	

KEY OTY PART DESCRIPTION 1 1 1 148121 A148121 ABL 2 1 840553 A840553 CONN. BODY/M B-PIN 3 1 141607 A141607 CONN. HODD, SERIES 2 4 2 840552 CONN. PIN/F SERIES 1 4 2 840552 CONN. PIN/F SERIES 2 5 1 141603 TUBING, HEAT SHRINK 3/4"	$\begin{array}{c c} \hline MOD. CONN. \\ \hline 1 \\ \hline 1 \\ \hline 2 \\ \hline 3 \\ \hline 5 \\ \hline 5 \\ \hline 7 \\ \hline 7 \\ \hline 7 \\ \hline 8 \\ $	Image: Second state in the se
ASSEMBLY INSTRUCTIONS 1. CUT OUTER JACKET TO LENGTH SHOWN. 2. CLIP UNUSED WIRES. 3. STRIP WIRE ENDS TO LENGTH SHOWN. 4. CRIMP PINS, KEY 4, ON WIRE ENDS. SEE TABLE. 5. INSERT PINS INTO KEY 2, USING TABLE. 6. PLACE HEAT SHRINK TUBING, KEY 5, OVER CABLE AND SHRINK DOWN OVER CONNECTOR HOOD, KEY 3, AND CABLE.	TABLE TABLE TABLE TABLE SCALE 2" = 1" SCALE 2" = 1" SCALE 2" = 1"	A 93-40 RELAKED 10/11/95 Å. REV NUMBER DESCRIPTION OF CHANGE DATE CA

KEY DTY PART NUMBER DRWG. NO. DESCRIPTION 1 1 1 141603 A141603 TUBING, HEAT-SHRINK 3/4" 2 1 141607 A141607 CONN, HOOD, SERIES 2 3 #000 A840500 A141820 CABLE, 4 WIFH SHIELD 4 1 840550 A840500 TUBING, HEAT-SHRINK 3/8" 5 5 2 840552 A840552 CONN, BINC, HEAT-SHRINK 3/8" 5 6 1 840553 B840553 CONN, BODY/F & PIN SERIES 2 2	AS REQUIRED AS REQUIRED 125	And the second secon
ASSEMBLY INSTRUCTIONS 1. CUT OUTER JACKET TO LENGTHS SHOWN. 2. CLIP UNUSED GREEN & WHITE WIRES & SHIELD WIRE. 3. STRIP WIRE ENDS TO LENGTH SHOWN, CRIMP PINS (KEY 5) ON WIRE ENDS. 4. INSERT PINS INTO KEY 6, USING TABLE 1. 5. PLACE HEAT SHRINK TUBING OVER CONNECTOR HOOD, KEY 2.		A 92-63 RELAGED 10/13/92 REV NUMBER DESCRIPTION OF CHANCE DATE

Description: Weigh Method is the

technique used to determine the displayed weight value.

Different *electronic* techniques are used in an attempt to better fit the weighing application. The EZ Scale Indicators provide four(4) different methods:

Weigh Method Setting Characteristic

1	General
2	Slow
3	Fast
4	Lock On

Weigh Methods 1, 2, & 3 are suitable for <u>all</u> weighing applications. Method 4, *Lock On*, works best for animal weighing.

General - Weigh Method #1:

The *General* weigh method is the *all purpose* weigh method. It is used for most applications. *General* is similar to the weigh method used on J-Star's *Model 5, 10, 15, & 20.* A comparison would be a *Model 10* with a TC (Time Constant) of 4.

Slow - Weigh Method #2:

The *Slow* weigh method attempts to provide higher accuracy by filtering many weight samples over a longer period of time. Small, instantaneous *weight changes* have less effect on the displayed weight using this technique.

Fast - Weigh Method #3:

The *Fast* weigh method is more sensitive to weight changes than the other weigh methods. When a weight changes quickly, the *Fast* method tries to determine the new weight as quickly as possible. This is done by providing less filtering during the actual *"weight change"*. When the weight begins to stabilize, filtering is increased to provide an accurate weight display.

Lock On - Weigh Method #4:

The *Lock On* weigh method is best suited to applications such as weighing animals.

Lock On has the ability to determine the actual weight of items while in motion, such as animals. Once the actual weight is displayed, the scale "Lock's On" to the displayed weight and does not change, <u>even</u> <u>if the motion never stops</u>. A small 'L' appears on the left side of the display indicating the weight is "Locked On". A dollar sign (\$) appears in the far left digit of the Scoreboard Data also indicating the "Locked On" weight.

In order to *break the lock*, 50% of the displayed weight must be either added or removed from the scale.

The "Locked On" weight can be "rechecked" by pressing the [ZERO] key on the front panel. This breaks the "lock" and the scale recalculates the displayed weight.

Index

.4mV/V 40
+RANGE 46
-RANGE 46
^ 43.54.55
1L PRT 44 49 54
$20 \text{m} \Delta$
20IIIA
20R 12, 21, 38, 45, 49
A/D
ADD WT 43, 49
AL OUT 43, 49
alarm 7, 11-15, 20-22, 31, 32, 34, 35,
38, 41, 43, 49
alarm lamp
Alarm Output 11 14 20 34 43 49
alpha-numeric display
AMI/PMI
Amount per Animal $\ldots 24, 27, 41$
Amount per Load 24-27, 41
Analog-to-Digital 44
Annunciators
Appendix A: 40, 48
Appendix B: 49
Appendix C: 50
Appendix D: 57
Appendix E: 64
Appendix E
auto-advance
auto-print 15, 35, 44, 52, 53
backlighting 5, 38
balancing 5
Batch
battery 6, 8, 9, 14, 18, 34
Baud 50
Black Out
bottom panel 5 8 14 15 34 35 38 50
Buzzer // // // // // // // // /// /// //////
$\begin{array}{c} \text{Duzzer} & \dots & $
$\begin{array}{c} \text{cable} \dots \dots$
CAL 15, 22, 24, 51, 52, 38, 40, 45,
47-49
Calendar 41, 49
Calibration 5, 9, 10, 18, 19, 39-49, 51
Calibration Number 40, 45, 48, 51
calibration value
CAP 42. 43. 49
Capacity
Capacity Limit 42 43 46
CHGCAP /2
CIEAD = 12 12 15 17 21 22 7 44
ULEAK 12, 15, 15-17, 21, 25, 57, 44,
51-53
Clear Memory 15, 44, 51-53
Clock 15, 17, 35, 37, 41, 52-55
Clock AM/PM 41

Clock Calendar	41
Clock Marque	41
Clock Time	41
CLR M	49
Command Set	51
communication format	50
Computer 45 50 51	56
$\begin{array}{c} \text{Computer Interface} \\ 51 \end{array}$	56
$\begin{array}{c} \text{COIDURT} & 6 & 0 & 17 & 18 & 27 & 40 & 42 & 46 \\ \text{COUNT} & & 6 & 0 & 17 & 18 & 27 & 40 & 42 & 46 \\ \end{array}$	10
$\begin{array}{c} \text{COUNT} \dots 0, \ 9, \ 17, \ 10, \ 57, \ 40, \ 42, \ 40, \\ \text{D} \text{ D} \text{ A} \text{TE} \end{array}$	49
$D \text{ KATE } \dots $	49
	50
DATE 17, 37, 41, 49, 52-	-22
$DELAY \dots 31-33, 42, 44, 49,$	55
Delay - Batcher	42
delay time 31-33,	42
diagnostics	45
Display Count Increment	42
Display Count Index	40
display mode 11,	20
Display Program ID:	45
display segments	45
Display Test	45
Display Units	42
Display Update Rate 42.	49
DSP AD 44	49
E MTHD 24 41	49
Edit	29
Entering & Exiting Setup Modes	39
Entry Method 24 28 29 41	<i>4</i> 9
Entry Method - Batcher	
araso 12 22 24 20	20
erase	30 45
$\mathbf{E}_{\mathbf{T}} \mathbf{W}_{\mathbf{T}} \mathbf{W}$	40
ESI WI	49
Estimated weight \dots 12 12 17 18 21	44
Example 6, 9, 12, 13, 17, 18, 21, .	2Z,
24, 28, 29, 31, 32, 37, 4	40,
41, 45, 51,	54
EXIT 13, 22, 24, 28-33, 35, 39, 41, 4	42,
44,	49
Exiting Setup/Calibration	44
Extension Kits 8, 14,	34
EZ 150 1, 5, 39,	43
EZ 210 1, 5, 39, 43,	49
EZ 3201, 5, 28, 29, 43,	49
EZ R & EZ VIEW	38
EZR 38, 43,	49
Fast	64
FEATURES 5. 7. 15.	35
Fiber-optic	38
formula	-30
Front Panel Alarm Light 11 20	43

Full Scale Calibration43
Gain 40, 43, 48
Getting Started 5
GOOD 43
GROSS 5-7, 9-11, 13, 15, 17-20, 22, 35,
37, 42, 44, 45, 47, 49,
51-54, 56
GROSS mode 5-7, 9-11, 18-20, 44, 47,
51, 54
grounding rods 8, 14, 34
Halting the Test 45
Handshake lines 50
HELLO 5, 6, 9, 18
HELP 5, 10, 19
Help Messages 5
horn 11, 20
ID # 15, 35, 47
identification number 15, 36, 47, 52-55
INGRED 43, 49
Ingredient \dots 5, 24-29, 31-33, 35, 41, 42,
49, 51, 53, 55, 56
Initiating Self Test:
Installation 1, 8, 14, 34, 38
$\begin{array}{cccccccccccccccccccccccccccccccccccc$
J901
1902 $3, 8, 14, 34$
J905
$\begin{array}{cccccccccccccccccccccccccccccccccccc$
$KG = \frac{10-42}{47-49} \frac{14, 54}{52}$
kilograms $A2 \ A7 \ A9 \ 52 \ 53$
I B 17 27 37 40-42 47 49 52 53
lightning 8 14 34
Lightning Protection 8 14 34
LO BAT 6 9 18
LOAD 5. 6. 8-12. 14. 18-21. 24-29. 33.
34, 41, 42, 47, 49, 51
LOAD/UNLOAD 10, 11, 19, 20
loadcell 5, 40
Lock 32, 33, 40, 42, 48, 49, 51, 52, 64
Long Form Calibration 42
Long Form Setup 21, 24, 31, 32, 38, 43,
49, 56
Loss of power 9, 18
low battery 6, 9, 18
$M+ \dots \dots \dots 15, 16, 47, 51-53, 56$
MARQUE 41, 49
maximum A/D counts 46
memory plus 15, 16, 51-53
message 5-7, 9, 10, 13, 17-19, 22, 24,
28-33, 37, 42, 43-46
minimum A/D counts 46
minus range

23 MOTION ... 31, 42, 43, 47, 49, 52, 55, 64 Mounting Bracket 8, 14, 34, 38 mud or snow accumulation 42 NET 6, 7, 9-13, 15, 17-22, 37, 38, 42, 44, 45, 47, 51-53, 55, 56 Net Mode 7, 10, 11, 19, 20, 47, 51, 55 NET/GROSS . . . 6, 7, 9-11, 13, 15, 17, 18, 22, 37, 42, 45 numeric keypad . . 11-13, 15, 20-23, 28-30, 33, 36, 44 **OPERATING SPECIFICATIONS** 5 option ... 7, 12, 15, 17, 21, 35, 37, 41, 43, 45, 52, 53, 54 Optional Features 7, 15, 35 output relay 11, 20 OVER 8, 14, 31, 34, 38, 41, 42, 46, 64 over-loading 42, 46 OVRCAP 46 P-ALM 13, 22, 24, 31, 32, 41, 49 parity bit 50 Percent(%) per Load 24 pounds 5, 17, 28, 29, 37, 42, 47, 49, 52-55 Power Connection 8, 14, 34 power cord 5, 8, 12, 14, 21, 34, 43, 49 POWER OUTAGE 17, 37 Pre-Alarm 11, 13, 20, 22, 31, 32, 41, 43.49 Pre-Alarm Weight . . . 13, 22, 31, 32, 41, 49 Preload a Tare Value 51 PRESET 11-14, 17, 20-22, 24, 31, 32, 34, 37, 39, 41, 43, 47, 49, 51 preset alarm 21, 43 preset condition 12 preset weight value 11, 20 PRINT 15, 16, 35, 44, 47, 49, 51-56 Print Delay 44 Printer 12, 15, 21, 35, 42, 47, 49, 50, 52.53.56 process control box 14, 34 Program ID: 45 programming recipes 24, 41 PROGRM 28-30 Pulsed Output 17, 37, 51 rated capacity 42 Raw A/D Display Counts 44

REC 2	28
REC-XX	30
RECALL 15, 16, 51-5	53
recall memory 15, 16, 51-5	53
RECIPE 5 19 24-33 35 42 43 4	7
51 53 55 4	56
regulated nower supply 8 14 3	3/
$\begin{array}{c} \text{Relation power suppry } \dots $	12
DEMOTE 7 12 14 15 21 24 25 2	+3 0
KENIOTE /, 12, 14, 13, 21, 34, 33, 3	0,
43, 49, 5	
Remote Display $/, 15, 35, 38, 2$	13
REMOTE ENTER PRESET \dots 12, 14, 2	1,
2	34
Remote Input 14, 21, 34, 43, 4	19
Remote Style 4	13
REMOTE ZERO 12, 2	21
RS-232 50, 5	51
RS-232 Specifications	50
RUNNING SELF TEST	15
scaling factor	16
Scoreboard 45 50-52 f	54
Solution $-5, 50-52, 0$	15
solf test operation	+J 15
Seriel Cohla Drawings	+3
Serial Cable Drawings)/
set the time	23
SETUP 9, 10, 13, 18, 19, 21, 22, 2	4,
31, 32, 38, 39, 40-49, 5	1,
31, 32, 38, 39, 40-49, 5 52, 5	1, 56
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number	1, 56 51
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number	1, 56 51 1,
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number	1, 56 51 1, 47
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number	1, 56 51 1, 47 51
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number	1, 56 51 1, 47 51 51
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5	1, 56 51 1, 47 51 51
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 5 Slow 40, 42, 44, 48, 49, 6	1, 56 51 1, 47 51 51 51
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 40, 42, 44, 48, 49, 6 Specifications 5	1, 56 51 1, 47 51 51 51 54 50
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 40, 42, 44, 48, 49, 6 Specifications 51, 32, 38, 39, 40-49, 5 52, 5 Short Form Calibration 9, 10, 18, 19, 39, 4 9, 40, 45, 48, 5 Short Form Calibration 51, 5 Short Form Setup 51, 5 Start Bit	1, 56 51 1, 47 51 51 51 51 54 50
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 2 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5	1, 56 51 1, 47 51 51 51 50 50 50
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 40, 42, 44, 48, 49, 6 Specifications 51, 52, 5 Start Bit 51, 52, 5 Stop Bit 2, 44, 48, 49, 6	1, 56 51 1, 56 51 1, 47 51 51 51 50 50 50 50 50 50 50 50 50 50 50 50 50
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 8, 14, 3	1, 56 51 1, 56 51 1, 47 51 51 51 50 50 50 34
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 5 System Errors 8, 14, 3 System Errors 40, 42, 41, 48, 49, 6	1, 56 51 1, 56 51 1, 75 1 51 51 51 50 50 50 34 45 15
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 5 System Errors 4 SYSTEM OPERATION 6, 9, 18, 38, 4	1, 56 51 1, 47 51 51 51 50 50 50 34 50 50 34 51 51
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 5 System Errors 8, 14, 3 SYSTEM OPERATION 6, 9, 18, 38, 4	1, 56 51 1, 56 51 1, 47 51 51 51 50 50 34 45 50 50 44 55 45 45 45 45 45 45 45 45 45 45 45
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 System Errors 8, 14, 3 System Errors 4 SYSTEM OPERATION 6, 9, 18, 38, 4 SYSTEM TEST 4 TARE 7, 10, 12, 13, 15, 19, 21, 35, 3	1, 56 51 1, 47 51 51 51 50 50 50 50 50 50 50 50 50 50 50 50 50
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 2 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 8, 14, 3 System Errors 4 SYSTEM OPERATION 6, 9, 18, 38, 4 SYSTEM TEST 42-44, 49, 51-5	1, 56 51 1, 75 1 51 51 50 50 34 55 45 8, 35
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 5 System Errors 4 SYSTEM OPERATION 6, 9, 18, 38, 4 SYSTEM TEST 42-44, 49, 51-5 Tare Auto-Print 44, 52, 5	1, 56 51 1, 7 51 51 51 51 50 50 34 55 45 53 53 53
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 5 System Errors 4 SYSTEM OPERATION 6, 9, 18, 38, 4 SYSTEM TEST 42-44, 49, 51-5 Tare Auto-Print 44, 52, 5 tare weight 12, 2	1, 56 51 1,7 51 51 51 51 50 50 50 45 45 45 8,3 53 21
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 5 System Errors 8, 14, 3 System Errors 42-44, 49, 51-5 Tare Auto-Print 44, 52, 5 Tare Auto-Print 44, 52, 5 TAREAP 44, 49, 52, 5	1, 56 51 1, 47 51 51 51 51 50 50 34 55 45 53 21 53
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 System Errors 8, 14, 3 System Errors 42, 44, 49, 51, 3 SYSTEM OPERATION 6, 9, 18, 38, 4 SYSTEM TEST 42-44, 49, 51, 5 Tare Auto-Print 44, 52, 5 tare weight 12, 2 TAREAP 44, 49, 52, 5 Terminating the Test 44, 49, 52, 5	1, 561 1, 471 511 514 500 500 445 545 8, 3 531 5345 45 535 153 45
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 2 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 System Errors 4 SYSTEM OPERATION 6, 9, 18, 38, 4 SYSTEM TEST 4 TARE 7, 10, 12, 13, 15, 19, 21, 35, 3 42-44, 49, 51-5 5 Tare Auto-Print 44, 52, 5 Terminating the Test 44, 49, 52, 5 Terminating the Test 44, 43, 45, 45	1, 561 1, 471 511, 471 511 514 500 500 345 455 8, 332 1354 532 1354 17
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 2 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 8, 14, 3 System Errors 4 SYSTEM OPERATION 6, 9, 18, 38, 4 SYSTEM TEST 4 TARE 7, 10, 12, 13, 15, 19, 21, 35, 3 42-44, 49, 51-5 5 Tare Auto-Print 44, 52, 5 tare weight 12, 2 TAREAP 44, 49, 52, 5 Terminating the Test 44, 49, 52, 5 Test Mode 6, 9, 18, 43, 45, 4	1, 56 1, 47 1, 51 1, 56 0, 50 3, 45 5, 56 3, 57 1, 57
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 5 System Errors 4 SYSTEM OPERATION 6, 9, 18, 38, 4 SYSTEM TEST 4 TARE 7, 10, 12, 13, 15, 19, 21, 35, 3 42-44, 49, 51-5 5 Tare Auto-Print 44, 52, 5 Terminating the Test 44, 49, 52, 5 Terminating the Test 44, 49, 52, 5 Test Mode 44, 49, 52, 5	1, 56 1, 47 1 1, 51 1, 51 1, 50 1, 5
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 5 System Errors 4 SYSTEM OPERATION 6, 9, 18, 38, 4 SYSTEM TEST 42-44, 49, 51-5 Tare Auto-Print 44, 52, 5 tare weight 12, 2 TAREAP 44, 49, 52, 5 Terminating the Test 44, 49, 52, 5 Test Mode 45, 9 Mode 45, 9	1, 56 51, 47 51, 47 51 51 50 50 50 45 55 45 53 53 15 54 55 15 55 14 55 50 50 50 50 50 50 50 50 50 50 50 50
31, 32, 38, 39, 40-49, 5 52, 5 Setup Number 40, 5 setup/calibration 9, 10, 18, 19, 39, 4 44, 4 short form 39, 40, 45, 48, 5 Short Form Calibration 45, 48, 5 Short Form Setup 45, 48, 5 Slow 40, 42, 44, 48, 49, 6 Specifications 5, 5 Start Bit 5 Stop Bit 5 Strain gage 8, 14, 3 System Errors 42 SYSTEM OPERATION 6, 9, 18, 38, 4 SYSTEM TEST 42 TARE 7, 10, 12, 13, 15, 19, 21, 35, 3 42-44, 49, 51-5 5 Tare Auto-Print 44, 52, 5 Terminating the Test 44, 49, 52, 5 Terminating the Test 44, 49, 52, 5 Test Mode 45, 9, 18, 43, 45, 4 Test Sequence 4 Atreshold 6, 9, 11, 12, 17, 18, 20, 2	1,651,7511400034555833135475583

31-33, 37, 41-44, 49, 52-55, 0	64
time of day 41, 4	49
Timer 23, 2	33
TOLER 31, 41, 4	49
tolerance	55
tolerance window	31
TOTAMT 24, 1	33
TR HLD 44, 4	49
TR Inventory Hold	44
TR/TR4	43
TR4 15, 35, 43, 44, 49, 52, 5	53
TR4 button #2	44
triangle 11, 20, 4	47
TUTORIAL	5
Under-range	46
unload	20
W MTHD 42, 4	49
Weigh Memory 16, 44, 4	47
Weigh Method 40, 42, 48, 49, 51, 5	52,
-	64
Weigh Method Descriptions	64
Weighing Errors	46
Wire	50
ZERO 5-7, 9-12, 17-21, 37, 41-44, 4	6,
49, :	51
Zero Tracking 42, 43, 4	49
ZERO/BALANCE 5, 6, 9, 17, 18, 3	37,
41, 42, 44, 1	51
ZTRACK	42
[CLEAR] key 17, 21, 22, 36, 2	37
[HELP] key 19, 2	39
[INGR.#] 28, 29, 31-33, 5	55
[M+] key	47
[NET/GROSS] key 5, 17-20, 23, 24, 3	31,
32, 37, 39, 41-4	43
[OFF] 18, 4	44
[ON] key 5, 22, 24, 28-32, 39-41, 43-4	45
[PRINT] key 32, 33, 35, 47, 52, 53, 5	55
[PROGRAM]	30
[RECIPE#] 28-30, 33, 35, 4	47
[TIMER]	23
[ZERO] key 5, 6, 9, 18, 30, 39, 40, 4	2,
	64

3 YEAR WARRANTY - ELECTRONIC SCALE PRODUCTS

GUARANTEE

J-STAR Industries, Inc. warrants for a period of 3 years from the date of manufacture, to correct by repair or replacement, at J-STAR's option, any defect in material or workmanship in any part of electronic scale products (unless otherwise specified on selected products). In the event of replacement, J-STAR's sole obligation shall be to provide replacement product or parts, FOB. Effective for product manufactured after January 1, 1991.

LIMITATIONS

This Limited Warranty does not apply to electronic scale products, accessories or parts not manufactured by J-STAR Electronics, except to the extent of the warranty given by the actual manufacturer thereof. Furthermore, this warranty shall not apply to:

- 1. Parts or products requiring replacement due to normal wear and tear, or due to improper installation, abuse, neglect or required maintenance, accident, fire, lightning or other acts of God.
- 2. Equipment that has been repaired or modified by person(s) not authorized by J-STAR, which in J-STAR's judgement has affected the performance or reliability.

J-STAR does not warrant any part or product to meet local, municipal, state, provincial or national laws and/or regulations.

EXCLUSION OF OTHER WARRANTIES AND REMEDIES

Except where such disclaimers and exclusions are specifically prohibited by applicable law, THE FOREGOING SETS FORTH THE ONLY GUARANTEE OR WARRANTY APPLICABLE TO THIS TRANSACTION, AND SUCH WARRANTY IS GIVEN EXPRESSLY AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, OR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ALL SUCH IMPLIED WARRANTIES WHICH EXCEED OR DIFFER FROM THE WARRANTY SET FORTH HEREIN ARE HEREBY DISCLAIMED BY J-STAR INDUSTRIES. Oral statements about the products covered by this transaction made by J-STAR's representatives, or statements contained in J-STAR's general advertising, pamphlets, brochures, or other printed matter, shall not constitute warranties. Except where such limitations and exclusions are specifically prohibited by applicable law, the SOLE AND EXCLUSIVE REMEDY AGAINST J-STAR SHALL BE FOR THE REPAIR OR REPLACEMENT OF DEFECTIVE PARTS AS PROVIDED, AND NO OTHER REMEDY (INCLUDING BUT NOT LIMITED TO INCIDENTAL, SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES FOR LOST PROFITS, LOST SALES, INJURY TO PERSONS OR PROPERTY, OR AN OTHER LOSS) SHALL BE AVAILABLE. This exclusive remedy shall not be deemed to have failed of its essential purpose as long as J-STAR is willing and able to repair or replace defective parts in the prescribed manner.

PRODUCT CHANGES AND IMPROVEMENTS

We reserve the right to make changes in design, to add improvements to or otherwise modify our electronic scale products without incurring an obligation on goods previously purchased and to discontinue supplying any parts listed when the demand does not warrant production.

J-STAR ELECTRONICS

801 Janesville Avenue Fort Atkinson, WI 53538 414-563-5521

AUTHORIZED WARRANTY CENTERS

ELECTRONIC SCALE PRODUCTS

Agri-Tronix Corporation 2001 North U.S. 31 Franklin, IN 46131 Telephone: 317-738-4474

Atlas Scale 83 Bridgeport Road East Waterloo, Ontario N2J 2K2 Canada Telephone: 519-885-5302

Controls and Weighing Systems, Inc. 205 Faulkenburg Road Tampa, FL 33619 Telephone: 813-681-5579

Electron Weigh, Inc. P.O. Box 1097 Highway 50 West Garden City, KS 67846 Telephone: 316-275-4227

Ferris Equipment R D 2 Sholtz Road P.O. Box 507 Oneida, NY 13421 Telephone: 315-363-4510

Harsh International Inc. 600 Oak Eaton, CO 80615 Telephone: 303-454-2291

Heyco Inc./Oswalt P.O. Box 1038 North Highway 83 Garden City, KS 67846 Telephone: 316-275-6101 Homer Scale Service 200 16th Street Hereford, TX 79045 Telephone: 806-364-6456

J-STAR Industries, Inc. Scale Group 801A Janesville Avenue Fort Atkinson, WI 53538 Telephone: 414-563-5521

Kirby Manufacturing 484 South Highway 59 P.O. Box 989 Merced, CA 95341-0989 Telephone: 209-723-0778

Mortec Industries, Inc. 515 Industrial Park Road P.O. Box 977 Brush, CO 80723 Telephone: 303-842-5063

Roto-Mix Inc. 2205 East Wyatt Earp P.O. Box 1724 Dodge City, KS 67801 Telephone: 316-225-1142

Schuler Mfg. & Equipment Co. R.R. 2, Box 68 Griswold, IA 51535 Telephone: 712-774-2228

Sioux Automation Center 877 1st Avenue NW Sioux Center, IA 51250 Telephone: 712-722-1488