



Capacity X 1000

Weigh Method			
1	2	3	4 = lbs
5	6	7	8 = kg.
General	Slow	Fast	Lock-on

Gain			
Gain Setting	Max Signal (mV/V)		
	EZ 150 EZ 210 EZ 320	EZ II Rev. 0A, 0B, 0C Software	EZ II Rev. 1.0 and Later Software
1	2.00	3.0	3.0
2	1.50	1.5	1.5
3	1.14	.75	1.5
4	.84	.75	.75
5	.47	.38	.75
6	1.90 (50Hz)	3.0	3.0
7	1.30 (50Hz)	1.5	1.5
8	.97 (50Hz)	.75	1.5
9	.66 (50Hz)	.38	.75

Gain Setting Requirement

Gain must be set above the maximum mV/V output expected on a system.

Example: Four cell 50K-CT system, 2.5 mV/V @ 200,000 lb.

Expected maximum load is 100,000 lb (1.25mV/V).

Setting should be □2" (1.5mV/V).

Display Counts (0-9)									
0	1	2	3	4	5	6	7	8	9
.01 .02 .05 .1	.2	.5	1	2	5	10	20	50	100
8 Select in long form only									

Display Count Setting Recommendation

Recommended display count setting equals capacity divided by 4,000.

Example: System has capacity of 40,000 lb.

Display count code should be "6" or more (10 lb/count or greater).

Capacity Setting Recommendation

Capacity should be set as low as possible, but must be set higher than the maximum safe gross load expected on the system.